


## SPINCASTING REEL G120A



Key No.	Parts No.	Parts Name	key No.	Parts No.	Parts Name
1	K06-0601	Front cover	19	B60-9202	Dial
2	B55-4001	Rotor nut	20	K00-5501	Anti-reverse pawl
3	K03-8702	Rotor	21	K00-1001	Anti-reverse pawl washer
4	320-0351	Spool retainer	22	B93-3001	Anti-reverse pawl screw
5	370-0412	Drag washer	23	K00-1101	Anti-reverse-lever
6	B81-1103	Spool	24	K00-1201	Anti-reverse-lever spring
7	370-0412	Drag washer	25	K00-2901	Drive gear
8	K06-0401	Main shaft	26	370-9900	Drive gear washer
9	K00-2601	Ball bearing	27	K00-7001	Bushing
10	K00-2701	Anti-reverse pawl spring	28	B01-3101	Bushing retainer
11	K00-2801	Anti-reverse ratchet	29	K06-2401	Side cover
12	402-6401	Pinion gear	30	K06-2701	Side cover screw
13	142-7712	Main shaft spring	31	K00-6001	Handle assembly
14	151-6731	Drag plate	32	160-8101	Handle lock washer
15	030-6001	Click pawl	33	K00-5901	Handle lock screw
16	B93-3001	Click pawl screw	34	K00-0601	Handle screw cap
17	K06-1001	Body	35	K00-2201	Line snubber
18	K06-2801	Drag Screw			