


SPINCASTING REEL GC80/GC100



Key No.	Parts No.	Parts Name
1	755-2203	Front cover
2	342-4911	Rotor nut
3	736-7701	Rotor
4	142-5111	Pick up pin spring
5	783-0001	Pick up pin
6	321-1001	Spool retainer
7	376-1901	Spool washer A
8	376-2101	Spool washer B
9	734-3211	Spool
10	376-2101	Drag washer A
11	376-2001	Drag washer B
12	151-8901	Drag adjusting plate
13	782-9932	Oscillating plate
14	364-0431	Drag adjusting screw
15	382-1721	Shaft bearing
16	394-1101	Main shaft
17	633-8811	Ball bearing
18	402-6401	Pinion gear
19	142-7711	Main shaft spring
20	701-6103	Body
21	352-2201	Collar stopper screw
22	502-0101	Drag adjusting collar
24	809-4401	Drag adjusting dial
25	781-6319	Push button
26	501-8501	Handle screw holder
27	363-8511	Handle screw A
28	803-4803	Handle screw cap
29	637-4801	Drive gear shaft holder
30	414-1801	Drive gear

Key No.	Parts No.	Parts Name
31	481-3011	Oscillating slider
32	375-0502	Drive gear washer A
33	280-9301	Ratchet
34	370-5100	Drive gear adjusting washer
35	636-6611	Bearing
36	063-3904	Body cover
37	111-7011	Anti-reverse claw
38	144-5111	Anti-reverse claw spring
39	351-7701	Anti-reverse claw screw
40	461-4501	Anti-reverse cam
41	809-1401	Anti-reverse cam spring
42	541-3132	Anti-reverse lever
43	351-4701	Anti-reverse lever screw
44	353-0001	Body cover screw (short)
45	353-4911	Body cover screw (long)
46	071-0505	Drive gear shaft
47	747-8101	Handle
48	160-8001	Handle washer
49	363-5302	Handle screw B

Special Parts for GC100

1	755-2303	Front cover
3-5	736-8001	Rotor assembly
3	376-8101	Rotor
5	783-0501	Pick up pin
9	734-3711	Spool
20	701-6203	Body
25	781-6320	Push button