


SPINCASTING REEL **RS100RL**



Key No.	Parts No.	Parts Name	Key No.	Key No.	Parts Name
1	B09-2104	Front cover	17	B07-9302	Drag adjusting dial
2	B55-4001	Rotor nut	18	B08-1812	Push button
3	B79-6101	Rotor	19	363-1911	Drag adjusting screw
4	B08-8206	Pick-up pin	20	501-8501	Handle screw holder
5	144-1801	Pick-up pin spring	21	E04-7802	Handle screw A
6	320-0351	Spool retainer	22	413-5201	Drive gear
7	370-0412	Spool washer	23	370-5150	Drive gear washer
8	K06-9001	Spool	24	062-9909	Body cover
9	370-0412	Spool washer	25	111-7012	Anti-reverse claw
10	K06-8501	Shaft metal	26	144-5111	Anti-reverse claw spring
11	K06-8701	Main shaft	27	351-7703	Anti-reverse claw screw
12	K00-2601	Ball bearing	28	351-1101	Body cover screw (short)
13	402-6401	Pinion gear	29	B08-2201	Body cover screw (long)
14	142-7712	Main shaft spring	30	071-0510	Drive gear shaft
15	151-6501	Drag adjusting plate	31	K06-8401	Handle
16	700-8825	Body	32	352-1101	Handle screw B