


SPINCASTING REEL **RS80RL**



Key No.	Parts No.	Parts Name
1	B09-2005	Front cover
2	B64-4201	Rotor nut
3	E04-8001	Rotor
4	B08-8203	Pick-up pin
5	B71-6101	Pick-up pin spring
6	320-0351	Spool retainer
7	370-0412	Spool washer
8	E04-7902	Spool
9	370-0412	Spool washer
10	K06-8501	Shaft metal
11	K06-8707	Main shaft
12	K00-2601	Ball bearing
13	402-6401	Pinion gear
14	142-7711	Main shaft spring
15	151-6501	Drag adjusting plate
16	E04-7302	Body

Key No.	Parts No.	Parts Name
17	B77-9302	Drag adjusting dial
18	B08-1813	Push button
19	363-5911	Drag adjusting screw
20	501-8501	Handle screw holder
21	E04-7802	Handle screw A
22	413-5201	Drive gear
23	370-5150	Drive gear washer
24	062-9909	Body cover
25	111-7012	Anti-reverse claw
26	144-5111	Anti-reverse claw spring
27	351-7703	Anti-reverse claw screw
28	351-1101	Body cover screw (short)
29	B08-2201	Body cover screw (long)
30	071-0510	Drive gear shaft
31	E04-8701	Handle
32	352-1101	Handle screw B