


SPINNING REEL

**BLACK GOLD BG-10**



Key No.	Parts No.	Parts Name
1	6-441-5301	Drag knob
2	6-151-7301	Drag spring washer
3	6-375-6001	Drag D washer
4	6-375-5902	Disc washer
5	6-B32-1101	Spool
6	6-B07-5302	Spool click claw
7	6-320-5901	Spool click claw retainer
8	6-144-1211	Spool click claw spring
9	6-375-5701	Spool washer
10	6-720-1331	Spool metal
11	6-151-7211	Spool metal leaf spring
12	6-B33-5301	Main shaft
13	6-636-7602	Oscillating support
14	6-B12-8201	Oscillating slider screw
15	6-341-9201	Rotor nut
16	6-B31-8101	Rotor
17	6-B18-8001	Bail kick cam spring
18	6-B32-0901	Bail kick lever
19	6-B31-8401	Bail kick lever cover
20	6-352-0401	Bail kick lever cover screw
21	6-353-8201	Bail holder screw
22	6-B18-8302	Bail
23	6-250-3921	Line roller
24	6-501-1401	Roller collar
25	6-353-8201	Arm lever screw
26	6-B18-7801	Arm lever
27	6-375-1001	Bail washer
28	6-353-8201	Bail screw
29	6-B18-7701	Bail spring

Key No.	Parts No.	Parts Name
30	6-B31-8501	Bail spring cover
31	6-352-0401	Bail spring cover screw
32	6-280-8901	Ratchet
33	6-145-0501	Anti-reverse claw spring
34	6-321-0801	Ball bearing ret. washer
35	6-351-0901	Ball bearing ret. washer screw
36	6-636-6401	Ball bearing
37	6-403-0701	Pinion gear
38	6-B33-5501	Body
39	6-B32-0701	Cam kick plate
40	6-363-2911	Cam kick plate screw
41	6-111-8301	Anti-reverse claw
42	6-041-6801	Anti-reverse claw plate
43	6-363-8801	Anti-reverse claw screw
44	6-461-7302	Anti-reverse cam
45	6-145-2701	Anti-reverse cam spring
46	6-371-6903	Anti-reverse lever washer
47	6-541-6801	Anti-reverse lever
48	6-353-4401	Anti-reverse lever screw
49	6-637-5701	Ball bearing
50	6-413-8911	Drive gear
51	6-481-1801	Oscillating slider
52	6-375-8500	Drive gear washer
53	6-637-5701	Ball bearing
54	6-B33-5401	Body cover
55	6-353-0001	Body cover screw
56	6-B03-4802	Handle screw cap
57	6-B33-5901	Handle