


SPINNING REEL

BLACK GOLD BG-13



Key No.	Parts No.	Parts Name
1	6-740-3311	Drag knob
2	6-170-4601	Drag washer retainer
3	6-374-4802	Drag D washer
4	6-373-3701	Disc washer
5	6-373-3603	Drag A washer
6	6-373-3704	Drag washer A
7	6-733-5005	Spool
8	6-B07-5302	Spool click claw
9	6-320-5901	Spool click claw retainer
10	6-144-1211	Spool click claw spring
11	6-375-5701	Spool washer
12	6-720-1721	Spool metal
13	6-151-7211	Spool metal leaf spring
14	6-B31-7601	Main shaft
15	6-637-0102	Oscillating support
16	6-351-5311	Oscillating slider screw
17	6-B10-5701	Rotor nut
18	6-B31-7901	Rotor
19	6-B18-4701	Bail kick lever spring
20	6-B32-1801	Bail kick lever
21	6-B32-7801	Bail kick lever cover
22	6-351-7701	Bail kick lever cover screw
23	6-353-8201	Bail holder screw
24	6-B18-5003	Bail
25	6-250-4221	Line roller
26	6-501-1601	Roller collar
27	6-353-8201	Arm lever screw
28	6-B18-4501	Arm lever
29	6-375-1001	Bail washer
30	6-353-8201	Bail screw
31	6-B18-4401	Bail spring

Key No.	Parts No.	Parts Name
32	6-B32-0201	Bail spring cover
33	6-351-7701	Bail spring cover screw
34	6-501-9901	Spring holder
35	6-145-0901	Anti-reverse claw spring
36	6-280-9001	Ratchet
37	6-501-9801	Spacer
38	6-321-0901	Ball bearing ret. washer
39	6-351-0901	Ball bearing ret. washer screw
40	6-635-4801	Ball bearing
41	6-403-2201	Pinion gear
42	6-B31-8001	Body
43	6-B32-1701	Cam kick plate
44	6-363-2911	Cam kick plate screw
45	6-111-8201	Anti-reverse claw
46	6-041-7101	Anti-reverse claw plate
47	6-363-9301	Anti-reverse claw screw
48	6-461-7104	Anti-reverse cam
49	6-144-0321	Anti-reverse cam spring
50	6-371-6903	Anti-reverse lever washer
51	6-541-6801	Anti-reverse lever
52	6-353-4401	Anti-reverse lever screw
53	6-637-5701	Ball bearing
54	6-414-1312	Drive gear
55	6-481-2101	Oscillating slider
56	6-375-8500	Drive gear washer
57	6-637-5701	Ball bearing
58	6-B31-7501	Body cover
59	6-353-0001	Body cover screw
60	6-B03-4802	Handle screw cap
61	6-B36-8401	Handle