


SPINNING REEL D1300B



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	740-3311	Drag knob	34	363-5201	Arm lever screw
2	171-7701	Drag washer retainer	35	501-1601	Roller collar
3	374-4802	Drag D washer	36	250-4221	Line roller
4	373-3701	Disc washer	37	501-9901	Spring holder
5	373-3603	Drag A washer	38	145-0901	Anti-reverse claw spring
6	373-3704	Drag washer A	39	280-9001	Ratchet
7	B39-3101	Drag plate	40	501-9801	Spacer
8	B39-1901	Spool	41	321-0901	Ball bearing ret. washer
9	B07-5302	Spool click claw	42	351-0901	Ball bearing ret. washer screw
10	320-5901	Spool click claw retainer	43	635-4801	Ball Bearing
11	144-1211	Spool click claw spring	44	403-2201	Pinion
12	375-5701	Spool washer	45	B25-4705	Body
13	720-1721	Spool metal	46	B22-3101	Cam kick plate
14	151-7211	Spool metal leaf	47	351-6601	Cam kick plate screw
15	711-4601	Main shaft	48	111-8201	Anti-reverse claw
16	637-0102	Oscillating support	49	041-7101	Anti-reverse claw plate
17	351-5311	Oscillating slider screw	50	363-9301	Anti-reverse claw screw
18	B10-5701	Rotor nut	51	461-7104	Anti-reverse cam
19	202-1036	Rotor	52	144-0321	Anti-reverse cam spring
20	145-0701	Bail kick cam spring	53	371-6903	Anti-reverse lever washer
21	571-0821	Bail kick cam	54	541-6801	Anti-reverse lever
22	354-0701	Bail kick cam screw	55	353-4401	Anti-reverse lever screw
23	B26-3101	Bail kick lever	56	637-4511	Bearing metal
24	041-7221	Bail kick lever cover	57	413-7701	Drive gear
25	351-7701	Bail kick lever cover screw	58	481-2101	Oscillating slider
26	145-1011	Bail spring	59	375-8500	Drive gear washer
27	041-7301	Bail spring cover	60	501-8502	Handle screw holder
28	351-7701	Bail spring cover screw	61	363-8511	Handle screw
29	725-8111	Bail	62	637-4511	Bearing metal
30	363-5201	Bail holder screw	63	B25-4805	Body cover
31	353-1811	Bail screw	64	353-0001	Body cover screw
32	375-1001	Bail washer	65	B03-4802	Handle screw cap
33	231-2901	Arm lever	66	B39-1701	Handle