


SPINNING REEL

REGAL-X2505T



Key No.	Parts No.	Parts Name
2-9	F49-3001	Spool assembly
1	F42-0906	Drag knob
2	F37-3301	Drag washer retainer
3	E46-7201	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F49-3103	Spool assembly
7	B07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	E46-7101	Spool washer
11	270-6501	Click gear
12	F45-4502	Main shaft
13	E45-1401	Oscillating slider
14	351-0315	Oscillating slider screw
15	341-9201	Rotor nut
16	F42-0806	Rotor assembly
17	B67-9308	Line roller screw
18	F45-2702	Bail arm
19	E49-3501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F44-6302	Line roller collar
22	F44-6201	Line roller washer
23	F47-3401	Line roller bushing
24	F45-4902	Line roller
25	F49-4201	Bail assembly
26	B84-2102	Bail trip cam screw
27	E45-1601	Bail trip lever
28	F18-0006	Trigger lever
29	E36-9901	Trigger spring
30	E41-7801	Trigger screw

Key No.	Parts No.	Parts Name
31	F12-8901	Bail spring
32	F31-0506	Bail spring cover
33	E36-4202	Bail spring cover screw
34	F31-0606	Bail trip cover
35	E49-2402	Anti-reverse ratchet
36	F37-5101	Spring holder
37	L03-6601	Ball bearing A
38	E51-9801	Pinion gear
39	F49-2702	Body assembly
40	L00-1801	Anti-reverse pawl screw
41	F37-5001	Anti-reverse pawl
42	L01-4302	Anti-reverse pawl collar
43	L00-1501	Anti-reverse pawl spring A
44	E03-7801	Bearing retainer screw
45	E32-7801	Anti-reverse cam spring
46	F00-5120	Anti-reverse lever
47	E45-1301	Oscillating gear
48	F17-0001	Drive gear
49	373-7805	Drive gear washer
50	631-6901	Ball bearing B
51	F49-2802	Side cover
52	B83-5002	Side cover screw
53	F49-9701	Handle assembly
54	F40-4801	Handle collar
55	B92-5011	Handle lock screw
56	F38-4701	Anti-reverse pawl spring B
57	F40-1001	Bail holder washer