


JH5000



Key No.	Parts No.	Parts Name
1	W30-4604	BODY
2	W30-8902	PINION GEAR
3	W30-1501	BALL BEARING
4	W30-1601	BEARING RET
5	W30-3801	BODY COLLAR
6	W30-7801	SPRING HOLDER
7	W30-7701	A/R PAWL SPRING B
8	W30-7601	A/R RATCHET
9	W30-5001	OSC SLIDER HOLDING PLT
10	W30-7003	A/R LEVER
11	W30-8001	A/R CAM
12	W30-8101	A/R LEVER SCREW
13	W30-7101	A/R CAM SPRING
14	W30-7301	A/R PAWL
15	W30-9501	BEARING RET SCREW
16	W30-7501	A/R PAWL SPRING
17	W30-7401	A/R PAWL SCREW
18	W30-8404	ROTOR
19	W31-1103	BAIL TRIP COVER
20	W30-2701	BAIL TRIP COVER SCREW
21	W31-1001	BAIL HOLDER SCREW
22	W30-1801	BAIL HOLDER COLLAR
23	W30-1701	BAIL ARM SCREW
24	W31-2101	BAIL SPRING SHAFT
25	W30-0903	BAIL ARM
26	W30-9001	BAIL SPRING
27	W31-2301	BAIL SPRING HOLDER
28	W31-1901	BAIL TRIP LEVER COLLAR
29	W31-1701	BAIL TRIP LEVER SPRING
30	W31-1301	BAIL TRIP LEVER
31	W31-1501	BAIL TRIP LEVER SCREW
32	W30-1304	BAIL SPRING COVER
33	W30-2701	BAIL SPRING COVER SCREW
34	W30-0402	BAIL
35	W30-5901	LINE ROLLER COLLAR
36	W30-6101	LINE ROLLER WASHER A

Key No.	Parts No.	Parts Name
37	W30-6901	LINE ROLLER
38	W30-6201	LINE ROLLER WASHER B
40	W30-5701	LINE ROLLER SCREW
41	W30-8201	ROTOR NUT HOLD PLT
42	W30-8701	ROTOR NUT
43	W30-6501	ROTOR NUT WASHER
44	W30-6301	ROTOR NUT LOCK SCREW
45	W30-6701	MAIN SHAFT
46	W30-2001	CLICK GEAR
47	W30-6801	SPOOL WASHER
48	W30-5601	OSC GEAR COLLAR
49	W30-5401	OSC GEAR
50	W30-5301	OSC SLIDER
51	W30-5101	OSC SLIDER SCREW
52	W30-3401	DRIVE GEAR
53	W30-4401	DRIVE GEAR WASHER
54	W30-4201	SIDE COVER BUSHING
55	W30-2504	SIDE COVER
56	W30-2601	SIDE COVER SCREW
57	W30-2803	HANDLE
58	W30-6401	HANDLE LOCK SCREW WASHER
59	W30-3003	HANDLE LOCK SCREW
60-67	W31-0503	SPOOL
61	W30-1901	CLICK PAWL
62	W30-2101	CLICK SPRING
63	W30-2201	CLICK PAWL SCREW
64	W30-3201	DRAG WASHER
65	W30-4801	KEY WASHER A
66	W30-4501	EARED WASHER
67	W30-9601	DRAG WASHER RET
68	W30-3103	DRAG KNOB
69	W30-9203	REAR COVER
70	W30-9401	REAR COVER SCREW
71	W30-4901	OSC SLIDER HOLD PLT SCREW
72	W31-1801	BAIL TRIP LEVER WASHER