


SPINNING REEL RB1000



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	B67-9901	Drag knob	24	B68-4401	Rotor washer A
2	170-7701	Drag washer retainer	25	B67-8801	Rotor washer B
3	374-9802	Drag D washer	26	634-1301	Ball bearing
4	374-3602	Disc washer	27	B68-9501	Pinion gear
5	374-3802	Drag A washer	28	B68-9201	Body
6	B69-1001	Spool	29	461-7701	Anti-reverse cam
7	372-3501	Spool washer	30	150-1751	Anti-reverse lever washer
8	B71-2801	Main shaft	31	B18-7401	Anti-reverse lever
9	B67-9401	Rotor nut	32	351-8302	Anti-reverse lever screw
10	B68-9601	Rotor	33	351-6102	Ball bearing screw
11	B45-1001	Bail kick lever	34	B07-3303	Bearing
12	B68-1301	Bail kick lever cover	35	B69-0001	Drive gear
13	352-0402	Bail kick lever cover screw	36	B19-0501	Oscillating slider
14	B18-7702	Bail spring	37	121-1211	Oscillating slider pin
15	B68-1201	Ball spring cover	38	371-2800	Drive gear washer
16	352-0402	Bail spring cover screw	39	B07-3303	Bearing
17	B67-9301	Bail screw	40	B69-0401	Body cover
18	B68-9701	Arm lever	41	B68-2301	Anti-reverse claw
19	351-6102	Arm lever screw	42	B50-1201	Anti-reverse claw plate
20	B68-5701	Roller collar	43	351-6102	Anti-reverse claw screw
21	250-3921	Line roller	44	351-8504	Body cover screw
22	B68-9801	Bail	45	B69-0701	Handle
23	351-6102	Bail holder screw	46	B68-2601	Handle screw cap