


SPINNING REEL RG 4000/RG 4000SC



Key No.	Parts No.	Parts Name
1	000-8241	Drag knob
2	170-4511	Drag washer retainer
3	376-0101	Drag D washer
4	372-6504	Disc washer
5	375-5401	Drag A washer
6	372-3004	Drag washer A
7	B69-5401	Spool
8	145-2101	Spool click claw spring
9	B07-8201	Spool click claw
10	320-1402	Spool click claw retainer
11	B35-3301	Spool washer
12	711-5801	Main shaft
13	637-4111	Oscillating support
14	351-8901	Oscillating slider screw
15	B68-1701	Rotor nut
16	202-1702	Rotor
17	363-3111	Bail screw
18	375-1101	Bail washer
19	231-3501	Arm lever
20	363-5202	Arm lever screw
21	501-2001	Roller collar
22	250-4501	Line roller
23	502-1401	Roller metal
24	725-8703	Bail
25	363-5202	Bail holder screw
26	B21-1801	Bail spring
27	B01-4003	Bail spring cover
28	351-6101	Bail spring cover screw
29	571-1201	Bail kick lever
30	041-9203	Bail kick lever cover
31	351-6101	Bail kick lever cover screw
32	145-3001	Bail kick cam spring
33	571-1101	Bail kick cam
34	353-8201	Bail kick cam screw
35	502-1301	Spring holder

Key No.	Parts No.	Parts Name
36	145-2901	Anti-reverse claw spring
37	B10-0801	Ratchet
38	636-6711	Click gear
39	050-5101	Ball bearing ret. washer
40	351-6601	Ball bearing ret. washer screw
41	635-5001	Ball bearing
42	403-3301	Pinion gear
43	B69-5001	Body
44	352-1102	Anti-reverse claw screw
45	B24-1601	Anti-reverse claw
46	351-6601	Cam kick plate screw
47	B22-9901	Cam kick plate
48	144-0321	Anti-reverse cam spring
49	B15-6402	Anti-reverse cam
50	373-2700	Anti-reverse lever washer
51	541-7301	Anti-reverse lever
52	352-2501	Anti-reverse lever screw
53	501-6102	Bearing
54	414-2901	Drive gear
55	481-2701	Oscillating slider
56	371-2800	Drive gear washer
57	501-6102	Bearing
58	B69-5201	Body cover
59	351-5901	Body cover screw
60	B68-7501	Handle
61	363-4702	Handle screw cap

RG4000SC Special Parts

16	202-1704	Rotor
35	B21-8901	Spring holder
37	280-9702	Ratchet
38	B21-8801	Click gear
43	B69-5002	Body
58	B69-5202	Body cover