


## SPINNING REEL RS 1000



Key No.	Parts No.	Parts Name
1	740-2304	Drag knob
2	170-7701	Drag washer retainer
3	374-9802	Drag D washer
4	374-3602	Disc washer
5	374-3802	Drag A washer
6	B17-9401	Spool
7	144-1211	Spool click claw spring
8	B07-5302	Spool click claw
9	320-5901	Spool click claw retainer
10	372-3501	Spool washer
11	B49-9001	Main shaft
12	341-9201	Rotor nut
13	B49-8601	Rotor
14	B47-9501	Tension spring A
15	B18-8101	Bail kick lever
16	B49-8801	Bail kick lever cover
17	352-0401	Bail kick lever cover screw
18	B18-7701	Bail spring
19	B18-7901	Bail spring cover
20	352-0401	Bail spring cover screw
21	353-8201	Bail screw
22	375-1001	Bail washer
23	B18-7801	Arm lever
24	353-8201	Arm lever screw
25	501-1401	Roller collar

Key No.	Parts No.	Parts Name
26	250-3921	Line roller
27	B18-8301	Bail
28	353-8201	Bail holder screw
29	B49-8501	Rotor washer
30	634-1301	Ball bearing
31	B49-8401	Pinion gear
32	B49-8101	Body
33	461-7701	Anti-reverse cam
34	150-1751	Tension spring B
35	B18-7401	Anti-reverse lever
36	351-8301	Anti-reverse lever screw
37	353-8201	Ball bearing screw
38	B12-9001	Bearing
39	B49-8901	Drive gear
40	B19-0501	Oscillating slider
41	121-1211	Oscillating slider pin
42	373-0100	Drive gear washer
43	B12-9001	Bearing
44	B49-9201	Body cover
45	B48-0501	Anti-reverse claw
46	B50-1201	Anti-reverse claw plate
47	351-6102	Anti-reverse claw screw
48	351-5901	Body cover screw
49	B49-9501	Handle
50	B22-4501	Handle screw cap