


## SPINNING REEL ST1375/1675



Key No	Parts No.	Parts Name
1	E13-3902	Spool assembly
2	E11-8401	Main shaft assembly
3	B97-9602	Oscillating slider
4	B97-9701	Oscillating slider retainer
5	B10-5701	Rotor nut
6	E10-7802	Rotor assembly
7	E10-8701	Bail trip lever
8	E10-8801	Bail trip cover
9	B83-4401	Bail trip cover screw
10	B67-9303	Line roller screw
11	B67-4601	Bail arm
12	B83-3801	Bail arm screw
13	320-5901	Bail arm screw retainer
14	B55-4301	Line roller washer
15	250-3921	Line roller
16	B45-1501	Line roller bushing
17	E11-7501	Bail
18	B83-4201	Bail trip cam screw
19	320-5901	Bail trip cam screw retainer
20	B83-3701	Bail spring
21	B83-3901	Bail spring cover
22	B67-4901	Trigger plate
23	B68-8801	Bail spring cover screw
24	B67-5201	Trigger spring
25	B67-5105	Trigger lever
26	B68-8802	Trigger screw
27	B68-6401	Spring holder
28	145-0901	Anti-reverse pawl spring
29	B67-4301	Anti-reverse ratchet
30	B44-0401	Spacing sleeve
31	B35-6301	Bearing retainer
32	B83-4402	Bearing retainer screw
33	B55-3401	Ball bearing
34	B55-5001	Bearing washer
35	B43-5801	Pinion gear
36	E11-7201	Body
37	B44-0501	Anti-reverse pawl screw
38	B74-5501	Anti-reverse pawl
39	375-2001	Anti-reverse pawl washer
40	E10-7501	Anti-reverse lever spring
41	E10-7601	Anti-reverse lever
42	E12-3501	Drag lever washer A
43	B89-9205	Drag lever
44	160-8101	Drag lever lock washer
45	B91-2101	Drag lever screw

Key No	Parts No.	Parts Name
46	E11-7901	Drag lever stop pin
47	E11-7801	Drag lever stop spring
48	E11-8101	Drag lever stop release
49	E11-8001	Drag lever plate
50	B01-3101	Key washer retainer
51	B49-0001	Key washer A
52	E11-8201	Drag washer holder
53	E09-2301	Drag washer holder collar
54	375-0402	Drag washer
55	E02-4401	Key washer B
56	B89-9501	Eared washer
57	B81-1802	Drag washer retainer
58	E11-8301	Drag coil spring
59	B93-5501	"O" ring
60	E11-7401	Drag screw
61	E12-3501	Drag cam washer
62	E11-7701	Drag cam
63	E03-3201	Drag cam click spring
64	E12-7301	Drag adjusting leaf spring
65	B74-2501	Oscillating gear
66	B84-3901	Bushing
67	B67-6002	Drive gear
68	373-7800	Drive gear washer
69	B84-3901	Bushing
70	E11-8601	Side cover
71	B83-5001	Side cover screw
72	E11-9702	Drag lever washer B
73	B89-9205	Drag lever
74	160-8101	Drag lever lock washer
75	B91-2101	Drag lever screw
76	E11-8801	Handle assembly
77	B92-4901	Handle lock washer
78	E00-1802	Handle lock screw

### ST1675 Special Parts

1	E13-4002	Spool assembly
6	E10-8402	Rotor assembly
7	E11-0601	Bail trip lever
17	E11-9101	Bail
33	B54-6001	Ball bearing
36	E11-7202	Body
70	E11-8602	Side cover
76	E12-7701	Side cover screw