


TOURNAMENT-S6000RA



Key No.	Parts No.	Parts Name
2-9	G01-5301	SPOOL
1	G01-3301	DRAG KNOB
2	F71-0001	DRAG WASHER RET
4	F75-6001	DRAG KNOB CLICK PLT
5	F75-5801	DRAG WASHER A
6	F75-5701	EARED WASHER
7	F75-5501	DRAG WASHER B
8	F75-5601	KEY WASHER
10	F13-7501	SPOOL WASHER
11	F23-5701	SHAFT METAL
12	F23-5801	SHAFT METAL SCREW
13	B35-8601	BALL BEARING A
14	F23-5601	SHAFT METAL COLLAR
15	E12-2301	CLICK LEAF SPRING HOLDER
16	B74-7701	SPOOL CLICK LEAF SPRING
17	F80-2301	SPOOL METAL
18	F56-9701	MAIN SHAFT
19	F81-9002	ROTOR NUT HOLD PLT
20	352-2201	ROTOR NUT HOLD PLT SCREW
21	B43-7603	ROTOR NUT
22	F57-1404	ROTOR
23	F29-6801	BAIL TRIP LEVER SPRING
24	F24-3902	BAIL TRIP PLT
25	F23-4202	BAIL TRIP LEVER
26	F24-4604	BAIL TRIP COVER
27	F29-9501	BAIL TRIP COVER SCREW
28	F23-4404	LINE ROLLER SCREW
29	373-2701	LINE ROLLER WASHER A
30	F84-4901	BALL BEARING B
31	F51-0001	LINE ROLLER
32	F44-6202	LINE ROLLER WASHER B
33	G01-4501	BAIL
34	F23-3903	BAIL HOLDER SCREW
35	E32-6701	BAIL SPRING SHAFT
36	E31-3901	BAIL SPRING WASHER
37	F30-4301	BAIL SPRING
38	F24-3804	BAIL SPRING COVER
39	F19-7302	ROLLER CLUTCH WASHER
40	F76-5401	ROLLER CLUTCH
41	F18-3001	BEARING RET

Key No.	Parts No.	Parts Name
42	351-1101	ROLLER CLUTCH SCREW
43	F24-2401	SPACING SLEEVE
44	F24-4801	A/R RATCHET
45	637-6101	BALL BEARING C
46	F24-2302	PINION GEAR
47	B86-1702	BALL BEARING D
48	F25-2401	BALL BEARING SCREW
49	F24-7101	A/R PAWL SCREW
50	F24-2701	A/R PAWL
51	F24-2801	A/R PAWL SPRING
52	G01-4901	BODY
53	E32-7801	A/R CAM SPRING
54	F23-7506	A/R LEVER
55	320-5901	WORM SHAFT GEAR RET
56	E45-4101	WORM SHAFT GEAR
58	F26-0701	WORM SHAFT BUSH
59	F26-0601	WORM SHAFT
60	F26-0502	WORM SHIELD
61	F25-9402	OSC SLIDER
62	E26-4101	OSC PAWL
63	E26-4201	OSC PAWL BUSH
64	375-0801	OSC PAWL WASHER
65	E26-4301	OSC SLIDER COVER
66	352-1505	OSC SLIDER COVER SCREW
67	375-4101	OSC SLIDER WASHER
69	F23-2601	WORM SHAFT RET
70	F25-7002	WORM SHAFT COLLAR
71	F24-3501	REAR COVER
72	F60-5101	REAR COVER SCREW
73	B54-6001	BALL BEARING E
74	F08-7402	DRIVE GEAR
75	371-2824	DRIVE GEAR WASHER
76	635-4801	BALL BEARING F
77	F24-3409	SIDE COVER
78	F29-8902	SIDE COVER SCREW A
79	351-7802	SIDE COVER SCREW B
80	F40-9001	HANDLE COLLAR
81	F75-4901	HANDLE SCREW
82	G01-5001	HANDLE
83	160-8001	HANDLE SCREW WASHER