


FLY REEL 730



| Key No. | Parts No. | Parts Name |
|---------|------------|----------------------|
| 1 | 6-130-4701 | Cover |
| 2 | 6-144-1801 | Spool stopper spring |
| 3 | 6-541-3401 | Spool stopper |
| 4 | 6-B05-5001 | Cover screw |
| 5 | 6-375-3801 | Cover washer |
| 6 | 6-734-6501 | Spool |
| 7 | 6-701-6401 | Body |
| 8 | 6-030-6901 | Click claw |
| 9 | 6-310-2201 | Line guard |
| 10 | 6-350-8912 | Line guard screw |