


FLY REEL 732



KEY NO. 1 ~ 6
6-732-3011

SPOOL ASSEMBLY

KEY NO. 9 ~ 11
6-781-6601

STAND ASSEMBLY

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6-353-0001	Cover screw	15	6-144-2901	Friction spring
2	6-130-4701	Cover	16	6-171-3001	Body ring
3	6-375-3801	Cover washer	17	6-320-7601	Click spring retainer
4	6-144-1801	Spool stopper spring	18	6-151-5702	Click spring
5	6-541-3401	Spool stopper	19	6-750-4101	Click gear
6	6-732-3111	Spool	20	6-320-5901	Click claw retainer
7	6-353-3501	Screw	21	6-030-5201	Click claw
8	6-560-4701	Ring	22	6-461-3801	Cam
9	6-610-3401	Stand	23	6-706-4501	Body
10	6-050-8801	Stand pillar	24	6-151-5301	Click lever washer
11	6-353-3601	Stand screw	25	6-541-3501	Click lever
12	6-320-8901	Click gear retainer	26	6-352-2501	Click lever screw
13	6-050-8901	Pillar	27	6-353-3501	Screw
14	6-310-1401	Line guard			