


# TEAM DAIWA-Z105HL



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	F83-7901	R/S PLT	55	320-5901	CLUTCH TRIP PLT RET
2	F63-1301	SET PLT SCREW	56	F86-5301	CLUTCH LEVER
3	E16-7101	SET PLT SPRING	57	F94-5001	CLUTCH LEVER SPRING
4	F61-3302	BRAKE ADJ KNOB	58	F83-5401	CLUTCH LEVER WASHER
5	B33-9801	BRAKE DIAL RET A	59	F83-5301	CLUTCH LEVER SCREW
6	F63-7701	BRAKE DIAL WASHER	60	F84-5401	PINION GEAR
7	F05-1701	BRAKE CLICK SPRING	61	E21-9701	BEARING RET B
8	F61-3401	BRAKE DIAL RET B	62	F05-5601	BALL BEARING E
9	F83-8001	RIGHT SET PLT	63	F83-3401	L/S PLT
10	F93-9701	RIGHT SET PLT SCREW	64	351-1107	L/S PLT SCREW A
11	F71-7702	MAGNET HOLDER	65	F80-0501	PINION SHAFT
12	B54-3201	MAGNET HOLDER RET RING	66	B17-5401	SPOOL ADJ CAP METAL
13	375-7404	SPACER A	67	B17-5503	SPACER D
14	375-7411	SPACER B	68	F83-3901	CAST CONTROL CAP
15	F57-4303	SPACER C	69	F64-7201	DRIVE SHAFT WASHER A
16	F57-7702	BALL BEARING A	70	F05-5601	BALL BEARING F
17	E21-9701	BEARING RET A	71	F83-5701	DRIVE SHAFT RET
18-26	Z01-1452	SPOOL	72	F68-9501	CLUTCH TRIP PLT SPRING
27	F83-4001	FRAME	73	F21-1101	DRIVE SHAFT RET SCREW
28	F83-7501	REAR COVER	74	F83-5601	DRIVE SHAFT
29	351-1006	REAR COVER SCREW A	75	F83-6901	A/R RATCHET
30	351-1107	REAR COVER SCREW B	76	E42-5301	DRIVE SHAFT WASHER B
31	320-5901	WORM SHAFT RET	77	F83-7001	DRIVE GEAR
32	F65-5501	WORM SHAFT WASHER	78	F79-6102	EARED WASHER
33	B71-5601	WORM SHAFT HOLDER	79	F79-6201	DRAG WASHER A
34	F83-6501	LEVEL WIND GUARD	80	F79-6303	KEY WASHER A
35	F83-6201	LINE GUIDE PAWL HOLDER	81	F79-6401	KEY WASHER B
36	121-4212	LINE GUIDE PAWL	82	E42-5401	SPACING SLEEVE
37	F95-0200	LINE GUIDE WASHER	83	F60-2901	GEAR SHAFT COLLAR
38	342-4801	PAWL CAP	84	B55-3802	SPACING SLEEVE B
39	F05-5601	BALL BEARING B	85	F57-3901	ROLLER CLUTCH
40	F83-6601	WORM SHAFT	86	F58-2501	BALL BEARING G
41	F95-8401	DRIVE GEAR A	87	B55-3801	DRIVE SHAFT WASHER C
42	F28-3101	BALL BEARING C	88	F02-8201	CLICK LEAF SPRING HOLDER
43	F50-5701	DRIVE GEAR SCREW	89	F03-2401	CLICK LEAF SPRING
44	F83-6001	DRIVE GEAR B	90	150-8901	DRAG SPRING WASHER
45	F83-6401	STABILIZER BAR	91	373-7810	SPACING SLEEVE C
46	F83-7601	FRONT PLT	92	F57-6503	STAR DRAG
47	F83-4701	BALL BEARING COLLAR	93	F57-6601	FRICITION WASHER
48	B86-1701	BALL BEARING D	94	F83-7201	HANDLE
49	F83-5001	CLUTCH CAM	95	F83-7401	HANDLE NUT
50	F83-5801	YOKE	96	F57-7202	HANDLE NUT RET
51	F58-8001	YOKE SPRING	98	351-1006	L/S PLT SCREW B
52	F83-4901	CLUTCH TRIP PLT HOLDER	99	F96-7801	DRAG WASHER B
53	F83-4801	CLUTCH TRIP PLT	100	F26-2701	CAST CONTROL CLICK SPRING
54	F77-4603	CLUTCH TRIP PLT WASHER			