


BAITCASTING REEL PTA33



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	B85-5204	Left side cover	40	B85-4601	Anti-reverse lever
2	B66-1001	Brake adjusting knob	41	B65-0501	Anti-reverse lever spring
3	637-0601	"O" ring	42	B35-8901	Anti-reverse claw spring
4	B54-1701	Brake adjusting gear	43	B74-0501	Anti-reverse claw
5	320-4202	Brake adjusting gear retainer	44	B81-5501	Set plate spring
6	B86-2001	Magnet holder A	45	320-1402	Clutch ret. ring
7	B83-4402	Left side cover screw	46	B35-9001	Pinion yoke
8	B58-2501	Magnet holder B	47	144-7101	Pinion yoke spring
9	B54-3204	Magnet holder ret. ring	48	B85-4403	Pinion gear
10	375-7405	Bearing metal washer	49	B85-2407	Right side cover
11	B35-8601	Ball bearing	50	B36-0401	Right side cover screw (short)
12	B42-1601	Bearing retainer	51	B64-3101	Bush
13	B86-2601	Frame	52	B17-5401	Spool adjusting cap metal A
14	B85-6201	Frame post A	53	B17-5501	Spool adjusting cap metal B
15	B86-4101	Frame post retainer A	54	171-5201	"O" ring
16	B86-3501	Frame post B	55	B85-3404	Right spool cap
17	B86-3901	Worm shield spring	56	B85-3101	Right side cover screw washer A
18	B86-3801	Frame post screw	57	B85-3001	Right side cover screw washer B
19	B85-1501	Clutch lever	58	B91-1701	Right side cover screw (long)
20	B86-2801	Line guide A	59	373-7611	Gear shaft washer A
21	B86-3601	Line guide spring	60	B86-5001	Gear shaft
22	B86-3101	Line guide B	61	B86-5101	Ratchet
23	B86-3701	Line guard	62	B85-4801	Gear shaft washer B
24	B86-4101	Frame post retainer B	63	B36-0203	Drag washer A
25	320-5901	Worm shaft retainer	64	B85-4902	Drive gear
26	B86-3301	Worm shaft plate	65	B36-0301	Drag washer B
27	373-1301	Worm shaft holder washer	66	373-7800	Drag washer C
28	022-2201	Worm shaft holder	67	150-8901	Spring washer
29	B86-0901	Line guide holder	68	B86-1601	Ball bearing washer
30	B91-2601	Line guide pin	69	B86-1701	Ball bearing
31	375-4100	Line guide washer	70	B86-4201	Star drag
32	342-4801	Line guide nut	71	150-9001	Handle washer
33	B85-6301	Worm shield	72	B85-5103	Handle
34	B85-6401	Shield bush	73	B41-1701	Handle nut washer
35	B85-6501	Worm Shaft	74	320-8202	Handle nut retainer
36	B85-7003	Spool	75	B86-2401	Handle nut
37	B42-1601	Bearing retainer	76	040-3203	Handle nut plate
38	B35-8601	Ball bearing	77	353-8301	Handle nut plate screw
39	B86-1901	Set plate			