


BAITCASTING REEL SM-2



Key No.	Parts No.	Parts Name
1	6-760-4501	Left side cover
2	6-375-8501	Ball bearing washer A
3	6-637-4601	Ball bearing
4	6-320-6501	Ball bearing ret. ring
5	6-320-5901	Worm shaft retainer
6	6-376-1801	Worm shaft holder washer
7	6-022-2201	Worm shaft holder
8	6-352-4221	Left side cover screw
9	6-760-4601	Frame
10	6-051-4701	Frame post
11	6-782-8801	Line guide
12	6-121-4211	Line guide pin
13	6-022-2901	Line guide pin holder
14	6-375-4100	Line guide washer
15	6-342-4801	Line guide nut
16	6-637-1201	Worm shield
17	6-711-5101	Worm shaft
18	6-500-8011	Brake collar
19	6-733-0901	Spool
20	6-782-3401	Set plate
21	6-144-8601	Clutch lever spring A
22	6-782-3501	Clutch lever
23	6-041-4301	Clutch stopper plate
24	7-144-8801	Clutch stopper plate spring
25	6-144-8701	Clutch lever spring B
26	6-121-9701	Clutch stopper plate pin
27	6-750-6401	Pinion gear
28	6-770-1801	Anti-reverse claw

Key No.	Parts No.	Parts Name
29	6-373-7611	Gear shaft washer A
30	6-720-2001	Gear shaft
31	6-374-9302	Gear shaft washer B
32	6-413-8801	Drive gear
33	6-374-9305	Drag washer A
34	6-374-9401	Drag washer B
35	6-375-8701	Drag washer C
36	6-376-0001	Drag washer D
37	6-760-4401	Right side cover
38	6-353-1701	Right side cover screw
39	6-320-6501	Ball bearing ret. ring
40	6-637-4601	Ball bearing
41	6-502-0901	Ball bearing washer B
42	6-373-7502	Ball bearing ret. washer A
43	6-373-7500	Ball bearing ret. washer B
44	6-374-7221	Rubber washer
45	6-170-6701	"O" ring
46	6-342-1002	Right spool cap
47	6-150-8901	Spring washer
48	6-502-0801	Spacing sleeve
49	6-780-9804	Star drag
50	6-150-9001	Handle washer
51	6-747-1701	Handle
52	6-353-0701	Handle screw
53	6-341-5801	Handle nut
54	6-040-3201	Handle nut plate
55	6-353-8301	Handle nut plate screw