



1	889-0010	Drag knob assembly	17	889-0069	Main shaft
2	889-0064	Spool, aluminum	18	888-9405	Rotor cover and pinion screw
3	889-0065	Spool, graphite	19	889-0071	Rotor cover and pinion screw
4	889-0066	Bail wire assembly	20	889-0072	Bail trip plunger
5	863-2000	Bail screw	21	850-1600	Bail spring
6	866-7700	Line roller washer	22	889-0073	Internal bail trip lever
7	888-9402	Line roller ball bearing	23	889-0074	Anti reverse pawl
8	866-6700	Ceramic line roller	24	889-0075	Rotor
9	867-6800	Line roller insert	25	861-1600	Spacer washer
10	889-0067	Bail arm			
11	850-3800	Bail arm screw			
12	889-0013	Click washer kit			
13	889-0068	Spool hub assembly			
13A	889-0042	Drag Washers			
14	850-5900	Rotor nut retainer screw			
15	850-3900	Rotor nut retainer			
16	842-9900	Rotor nut			

26	889-0076	Anti reverse spring assmly
27	889-0077	Anti reverse on-off spring
28	893-4000	Anti reverse actuation race
29	889-0078	Pinion bearing retainer
30	889-0079	Anti reverse storn
31	889-0081	Body
32	888-9425	Handle nut
33	889-0082	Anti reverse switch
34	889-0083	Gear set
35	889-0084	Oscillation gear kit
36	889-0085	Oscillation slider plate
37	897-6200	Ball bearing
38	889-0023	Body cover
39	888-9412	Body screws
40	889-0086	Handle assembly

MCHT 40