



Part No.	Part Name
84043	BRASS ROLLER LINE GUIDE
84045	STEEL BAIL WIRE SCREW
84049	STEEL BAIL SPRING
84055	BAIL TRIP LEVER SPRING
84064	STEEL SPLIT PIN
84073	STEEL DRAG SPRING
84074	DRAG SPRING CASING
84075	DRAG SPRING CASING RETAINER
84076	STEEL DRAG KNOB INDEX
84077	DRAG ADJUSTING KNOB
84080	CLICK SPRING WASHER
84084	ANTI-REVERSE FRICTION
84088	OSCILLATION SLIDE SCREW
84100	ANTI-REV.RATCHET(SET2)
84104	BRONZE ANTI-REV LEVER
84105	HANDLE SCREW
84107	STEEL CLICK SPRING
84108	STEEL ANTI-REVERSE CLICK
84110	TRANSLATION SLIDE
84111	STEEL OSCILLATION ARM
84123	DRAG ASSEMBLY
84126	BRASS ROLLER RACE
84291	BAIL ARM
84293	STEEL BAIL ARM SCREW
84294	SCREW/BAILARM CVR & BRKT
84299	ROTATING HEAD HEX NUT
84469	BALL BEARING BRACE

Part No.	Part Name
84470	ARM COVER
84471	BRACKET COVER PLATE
84474	ROT HEAD BALL BEARING
84515	BUSHING
84571	SPOOL-STANDARD GRAPHITE
84572	STEEL BAIL WIRE
84573	ROTATING HEAD
84574	STEEL TRIP LEVER
84575	HANDLE COMPLETE
84601	STEEL AXLE
84602	BRASS ROT HEAD SPACER
84603	RELEASE LEVER SCREW
84604	STEEL COVER SCREW
84609	ANTI-REVERSE BUTTON
84610	STEEL DRAG KNOB SCREW
84611	STEEL CLICKSPRING SCREW
84612	STEEL ANTI-REVERSE SCREW
84618	PINION KIT SCREW
84626	DRIVE GEAR
84627	BRONZE PINION
84633	GRAPHITE COVER
84634	GRAPHITE HOUSING
84787	STEEL HEX NUT SCREW
84871	ADJ. WASHERS/MAIN GEAR
84873	BUSHING PLATE
84876	SLEEVE