



| Part No. | Description |
|----------|---------------------------|
| 8293100 | ROTATING HEAD BALLBEARING |
| 8319000 | OIL DUST SHIELD |
| 9321100 | SHIM - DRIVE GEAR |
| 8429300 | BAIL ARM SCREW |
| 8460400 | SIDE PLATE SCREW |
| 8505300 | ANTI-REVERSE SHAFT SPRING |
| 8505400 | RETAINER SCREW |
| 8505900 | MOUNTING SCREW |
| 8508300 | CRP SCREW WASHER |
| 8651600 | BAIL SPRING PIN |
| 8666700 | LINE GUIDE |
| 8667700 | LINE GUIDE WASHER |
| 8667800 | LINE GUIDE BUSHING |
| 8670300 | DRIVE GEAR |
| 8670400 | FINION GEAR |
| 8670600 | OSCILLATION SLIDE |
| 8670700 | BEARING RETAINER |
| 8671000 | ANTI-REVERSE SHAFT |
| 8671500 | TRIP LEVER |
| 8671700 | BAIL SPRING |
| 8672000 | ANTI-REVERSE FRICTION |
| 8672100 | DRIVE GEAR BUSHING |
| 8672200 | ANTI-REVERSE DOG |
| 8673100 | ANTI-REVERSE BUSHING |
| 8673200 | ROTATING HEAD WASHER |
| 8673600 | OSCILLATION SLIDE SCREW |
| 8674200 | BEARING |
| 8675100 | BUTTON & CLICK SCREW |

| Part No. | Description |
|----------|------------------------------|
| 8676100 | LINE GUIDE SCREW |
| 8676200 | HEX NUT RETAINER |
| 8676400 | BEARING WASHER |
| 8676800 | LINE GUIDE RACE |
| 8680200 | RETAINER SCREW |
| 8683000 | CROSS WIND GEAR |
| 8683600 | DRAG WASHER |
| 8684000 | BASE DRAG WASHER |
| 8684300 | SPOOL GEAR |
| 8684900 | FREE SPOOL CLICK |
| 8685000 | SPOOL CLICK |
| 8685100 | HEX NUT |
| 8685400 | FREE SPOOL FRICTN SCREW |
| 8685600 | AXLE |
| 8685800 | DRAG KNOB W/WASHER |
| 8685900 | SPOOL SPINDLE |
| 8686000 | SPOOL |
| 8686200 | FREE SPOOL FRICTION & SPRING |
| 8686400 | BAIL WIRE W/ COVER PLATE |
| 8915200 | ANTI-REVERSE BUTTON |
| 8815600 | BAIL ARM |
| 8815700 | ROTATING HEAD |
| 8815800 | COVER PLATE |
| 8815900 | HANDLE CAP SCREW W/WASHER |
| 8816200 | HANDLE |
| 8817500 | HOUSING |
| 8817600 | SIDE PLATE |