



Part No.	Description
8149300	BALLBEARING
8293100	ROTATING HEAD BALLBEARING
8319000	OIL DUST SHIELD
8321100	SHIM - DRIVE GEAR
8460400	SIDE PLATE SCREW
8505300	ANTI-REVERSE SHAFT SPRING
8505400	RETAINER SCREW
8505900	MOUNTING SCREW
8507100	DRAG CLICK
8507200	DRAG CLICK SPRING
8571300	LINE CLIP
8571400	LINE CLIP RETAINER
8666700	LINE GUIDE
8667700	LINE GUIDE WASHER
8667800	LINE GUIDE BUSHING
8671700	BAIL SPRING
8572100	DRIVE GEAR BUSHING
8673100	ANTI-REVERSE BUSHING
8673200	ROTATING HEAD WASHER
8674300	KEYED WASHER
8674400	DRAG HEX NUT
8674500	DRAG SPRING
8674600	DRAG WASHER
8674900	SPOOL CLICK
8675000	SPOOL CLICK SPRING
8675100	BUTTON & CLICK SCREW
8676000	HEX NUT
8676200	HEX NUT RETAINER
8676800	LINE GUIDE RACE

Part No.	Description
8677800	CLICK GEAR
8678000	BAIL SPRING PIN
8678200	TRIP LEVER
8678800	OSCILLATION SLIDE
8678900	OSCILLATION SLIDE SCREW
8679000	DRIVE GEAR
8679500	PINION GEAR
8679600	BEARING RETAINER
8679800	ANTI-REVERSE FRICTION
8680100	ANTI-REVERSE DOG
8680200	RETAINER SCREW
8680300	ANTI-REVERSE SHAFT
8680400	BAIL SCREW
8680800	LINE GUIDE SCREW
8682300	AXLE W/CLICK GEAR
8682400	BAIL WIRE W/COVER PLATE
8682900	CROSS WIND GEAR
8816300	DRAG KNOB
8816400	DRAG ASSEMBLY
8816500	SPOOL
8816600	BAIL ARM
8816700	COVER PLATE
8816800	ROTATING HEAD
8816900	HANDLE CAP
8817000	HOUSING
8817100	SIDE PLATE
8817200	ANTI-REVERSE BUTTON
8817300	HANDLE W/LUBE PORT
8817400	HANDLE COLLAR