



- | | | |
|---------|------------------------------|-------------------------------|
| 8889617 | 1. FRAME | 461. CRANK SHAFT WASHER |
| 8889618 | 2. CLUTCH BAR PIN | 462. CRANK SHAFT BALL BEARING |
| 8889619 | 3. CLUTCH BAR | 463. SET PLATE |
| 8889620 | 4. WEAR PLATE A | 464. CLUTCH CAM |
| 8889621 | 5. WEAR PLATE B | 465. SPRING COLLAR |
| 8889622 | 6. WASHER | 466. CLUTCH CAM SPRING |
| 8889623 | 7. RETAINER (2.5) | 467. CAM PLATE |
| 8889624 | 8. PILLAR B | 468. KICK LEVER |
| 8889625 | 9. WORM SHAFT | 469. KICK LEVER SPRING |
| 8889626 | 10. WORM SHAFT BUSH B | 470. WASHER |
| 8889627 | 11. LEVEL WIND | 471. CRANK SHAFT |
| 8889628 | 12. LEVEL WIND GUARD | 472. KICKING RATCHET |
| 8889629 | 13. WORM SHAFT BUSHING-A | 473. DRAG WASHER A |
| 8889630 | 14. WASHER | 474. DRIVE GEAR |
| 8889631 | 15. RETAINERS (2-5) | 475. KEY WASHER B |
| 8889632 | 16. PILLAR A | 476. DRAG WASHER B |
| 8889633 | 17. LINE GUIDE PAWL | |
| 8889634 | 18. LINE GUIDE WASHER | |
| 8889635 | 19. LEVEL WIND NUT | |
| 8889636 | 20. CLICK SET PLATE | |
| 8889637 | 21. SCREW-LEFT INSERT | |
| 8889638 | 22. WASHER | |
| 8889639 | 23. IDLE GEAR | |
| 8889640 | 24. WASHER | |
| 8889641 | 25. SCREW-LEVEL WIND GEAR | |
| 8889642 | 26. RETAINER (3) | |
| 8889643 | 27. WASHER | |
| 8889644 | 28. CLICK CLACK | |
| 8889645 | 29. CLICK CAM | |
| 8889646 | 30. PIN | |
| | 31. SPRING | |
| | 32. SCREW R | |
| | 33. COIL SPRING A | |
| | 34. CLICK LEVER | |
| | 35. COIL SPRING B | |
| | 36. SPACER | |
| | 37. LEFT SIDE COVER | |
| | 38. SCREW | |
| | 39. RETAINER | |
| | 40. GEAR | |
| | 41. BALL BEARING | |
| | 42. BRAKE COLLAR | |
| | 43. SPOOL ASSEMBLY | |
| | 44. RETAINERS (3) | |
| | 45. CRANK SHAFT WASHER | |
| | 46. CRANK SHAFT BALL BEARING | |
| | 47. SET PLATE | |
| | 48. CLUTCH CAM | |
| | 49. SPRING COLLAR | |
| | 50. CLUTCH CAM SPRING | |
| | 51. CAM PLATE | |
| | 52. KICK LEVER | |
| | 53. KICK LEVER SPRING | |
| | 54. WASHER | |
| | 55. CRANK SHAFT | |
| | 56. KICKING RATCHET | |
| | 57. DRAG WASHER A | |
| | 58. DRIVE GEAR | |
| | 59. KEY WASHER B | |
| | 60. DRAG WASHER B | |
| | 61. EARED WASHER | |
| | 62. KEY WASHER A | |
| | 63. PINION GEAR | |
| | 64. YOKE | |
| | 65. YOKE SPRING | |
| | 66. CLAM PLATE SCREW | |
| | 67. THUMB SCREW RING | |
| | 68. ONE-WAY BEARING | |
| | 69. SLEEVE | |
| | 70. DRAG SPRING WASHER | |
| | 71. STAR DRAG WASHER A | |
| | 72. STAR DRAG WASHER B | |
| | 73. STAR DRAG | |
| | 74. FRICTION WASHER | |
| | 75. HANDLE ASSEMBLY | |
| | 76. HANDLE NUT | |
| | 77. HANDLE NUT CAP | |
| | 78. HANDLE NUT CAP S/C | |
| | 79. RIGHT SIDE COVER | |
| | 80. THUMB SCREW WASHER | |
| | 81. THUMB SCREW | |
| | 82. BALL BEARING | |
| | 83. RETAINER | |
| | 84. O-RING | |
| | 85. SPACER B | |
| | 86. CUSHION WASHER | |
| | 87. CAST CONTROL CAP | |
| | 88. RIGHT SIDE COVER SCREW | |
| | 89. BEARING PLATE | |
| | 90. BALL BEARING | |