



EF-30a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21006515	MAIN BODY	703	27030024	PINION GEAR BUSHING
105	21050029	PINION BEARING FIXED PLATE	705	27050078	TRANSMISSION GEAR
108	21086560	CAP	708	27080065	OSCILLATING SLIDER
115	21150001	WUNG SCREW	716	27160007	OSCILLATION SLIDER PLAT
118-1	21180017	BALL BEARING HOLDER	717	27170002	WORM SHAFT SLIDER
120	21200001	MAIN BODY PIN	718	27180500	MAIN SHAFT
200	22007017	SIDE PLATE	719	27190025	CLICK GEAR
300	23006918	ROTOR	722	27220009	CLICK GEAR WASHER
301	23011272	BAIL ARM	722-1	27220010	CLICK GEAR WASHER
304	23043077	BAIL ARM COVER	725	27250020	TRANSMISSION GEAR BUSHING
305	23050088	KICK LEVER	725-1	27250002	TRANSMISSION GEAR BUSHING
307	23073071	BAIL HOLDER	800	28000242	ANTI-REVERSE/ANTI-RE LEVER
309	23090002	BAIL ARM SLIDER	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
310	23100001	COMPRESSION SPRING	801	28010024	ANTI-RE LEVER SPRING
313	23131042	BAIL WIRE ASSY	903	29030001	SPRING WASHER
315	23150011	LINE ROLLER	9101	0910330	ONE WAY
318	23180012	ROTOR NUT	9102	0910054	BALL BEARING
400	240010103	SPOOL ASSY.	9103	0910278	BALL BEARING
400-1	240010102	SPOOL ASSY.	9103-1	0910256	BALL BEARING
405	24050031	DARG WASHER RETAINER	9104	0910015	BALL BEARING
407	24070004	EXTENSION SPRING	9202	0920154	WASHER
413	24130002	WATERPROOF RETAINER	9203	0920075	WASHER
500	25002881	HANDLE ARM ASSY	9301	0930885	SCREW
504	25040009	HANDLE SCREW CAP WASHER	9301-1	0930374	SCREW
513	25130392	HANDLE SCREW CAP	9302	0930129	SCREW
600	26000817	DRAG KNOB ASSY.	9303	0930473	SCREW
610	26100049	DRAG WASHER	9304	0930237	SCREW
611	26110018	EARED WASHER	9305	0930229	SCREW
612	26120042	KEY WASHER	9306	0930964	SCREW
612-1	26120043	KEY WASHER	9308	0930838	SCREW
612-2	26120054	KEY WASHER	9309	0930639	SCREW
700	27000256	DRIVE GEAR	9313	0930575	SCREW
702	27020340	PINION GEAR	9326	0930611	SCREW