




# PARTS LIST FOR MODELS 720Z AND 722Z



KEY NO.	DESCRIPTION	PART NO.
1	Housing w/Bushing	001 720Z
*	*Housing w/Bushing	*001 722Z
4	Dog	004 720
5	Dog Spring	005 720
6A	Eccentric	006A720
6B	Eccentric Liner	006B720Z
6D	Eccentric Spring	006D720
6E	Eccentric Lever	006E710
8	Main Gear w/Ratchet	008 720
*	*Main Gear w/Ratchet	*008 722
12	Crosswind Screw	012 722
15	Handle Assembly (Complete)	015 720Z
*	*Handle Assembly (Complete)	*015 722Z
17A	Handle Cover Washer	017A720Z
18A	Handle Screw	018A720Z
19	Pinion Gear	019 720
*	*Pinion Gear	*019 722
19A	Gear End Spacer (722Z only)	019A722
19B	Rotor End Spacer (722Z only)	019B722
20	Pinion Bearing	020 720
*	*Pinion Bearing	*020 722
20A	Pinion Thrust Washer (720Z only)	020A720
21	Bearing Retainer (722Z only)	021 722
22	Eccentric Screw	022 109
24	Bail Wire	024 720
27	Rotor Cup	027 720Z
*	*Rotor Cup	*027 722Z
28	Bail Release Arm	028 720
29	Bail Release Arm	029 720
30	Arm Release Spring	030 720
31	Bail Screw	031 710
32	Bail Spring	032 720
34	Bail Arm	034 720
35	Line Roller	035 720
36	Bail Lock Nut	036 700
37	Rotor Cup Washer	037 720
38	Rotor Cup Nut	038 720
39	Spool Shaft Assembly	039 720
43	Crosswind Block	043 720
44	Crosswind Connector	044 720
45	Housing Plate	045 720Z
*	*Housing Plate	*045 722Z
46	Housing Plate Screw	046 720
47	Spool Assembly (Complete)	047 720Z
*	*Spool Assembly (Complete)	*047 722Z
48	Click Tongue	048 720
51	Retaining Spring	051 710
52	Drag Knob	052 720Z
56T	Drag Washer (Teflon®)	056 710
57	Metal Slot Washer	057 720
58	Metal Washer (Octagon)	058 720
60	Rear Drag Washer	060 712
61	Handle Knob	061 720Z
63	Click Screw	63 349

\* Not Shown