



Penn Reel Parts list for:

Model: 114-LH FULL Frame 6/0 Senator, Left Hand Version

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	1-114	Right Side Plate	24	24-57	Handle
2	2-114-O	Right/Left Side Ring Outer	26	26-114	Bearing Right Side
3	3-114LH	Bridge with Sleeve (LEFT HAND)	27	27-114	Left Side Plate
4	4-114	Fiber Washer	28	2N-114	Left Side Ring
5	5-114LH	Main Gear (LEFT HAND)	29	29M-114	Spool
6	6-114	Drag Washer	30	30-114HL	Stand
7	7C-114	Metal Drag Washer Set	32	32-21	L.S. Stand Screw (5 Required)
8	8-114	Tension Spring	33	33-340	Rod Clamp
8A	8-115	Tension Spring	34	34-114HLW	Clamp Screw (2 Required)
9	9N-114	Spacing Sleeve	35	35-114	Click Tongue
10	10-114	Star Drag Wheel	36	36-114H	Click Button
11	11-114	Eccentric Jack	39	39-12	L.S. Post Screw (5 Required)
12	12-114	Pinion Yoke	40	40-114	L.S. Bearing
13	13-114LH	Pinion (LEFT HAND)	41	41-114	L.S. Bearing Spring
14	14-114	Dog Spring	54	54-114	Harness Lug (2 Required)
15	15-114	Dog	62	62-114	Click Spring
16	16-114	Bridge Screw Lower (2 Required)	62A	63-209	Click Spring Screw
17	17-114	Bridge Screw Upper (2 Required)	69	69B-600	Retaining Ring
18	18-114	Clutch Spring	86	86-114L	Metal Drag Washer
19	19-114	Eccentric	98	98-114LH	Gear Sleeve (LEFT HAND)
20	20-114	Eccentric Spring	118	118-80	Stand Screws(4 req)
21	21-114	Eccentric Lever	136	136-114	Pressure Plate Washer
22	23-60	Eccentric Screw	140	140-114	Felt Washer
23	23-116	Handle Screw	149	149-45	Clamp Nut (2 Required)
23A	110-60	Handle Lock Screw	183	183-114T	Frame