



Penn Reel Parts list for:

KEY NO.	PART NO.	DESCRIPTION
1	1-114H	Right Side Plate
2	2N-114H	Right Side Ring Outer
3	3-114H-LH	Bridge with Sleeve (LEFT HAND)
4	4-115	Fiber Washer
5	5-115LH	Main Gear (LEFT HAND)
6	6-115	Drag Washer
7	7C-115	Metal Drag Washer Set
8	8-114	Tension Spring
8A	8-115	Tension Spring
9	9-114H	Spacing Sleeve
10	10-114	Star Drag Wheel
11	11-114	Eccentric Jack
12	12-114	Pinion Yoke
13	13-114H-LH	Pinion (LEFT HAND)
14	14-114	Dog Spring
15	15-114H	Dog
16	16-114	Bridge Screw Lower (2 Required)
17	17-114	Bridge Screw Upper (2 Required)
18	18-114	Clutch Spring
18A	18-114H	Spring Disc
19	19-114	Eccentric
20	20-114	Eccentric Spring
21	21-114	Eccentric Lever
22	23-60	Eccentric Screw
23	23-116	Handle Screw
23A	110-60	Handle Lock Screw

Model 114H-LH 6/0 Senator, Full Frame, Left Hand Version

KEY NO.	PART NO.	DESCRIPTION
24	24-57	Handle
26	26-116	Bearing Right Side
27	27N-114H	Left Side Plate
28	2N-114	Left Side Ring Outer
29	29L-114HL	Spool, Aluminum
30	30-114HL	Stand
32	32-21	L.S. Post Screw (5 Required)
33	33-340	Rod Clamp
34	34-114HLW	Rod Clamp Screw (2 Required)
35	35-114	Click Tongue
36	36-114H	Click Button
39	39-12	R.S. Post Screw (5 Required)
40	40-114HL	L.S. Bearing
40A	120-114H	L.S. Bearing O Ring
54	54-114	Harness Lug (2 Required)
62	62-114	Click Spring
62A	63-209	Click Spring Screw
69	69B-600	Retaining Ring
98	98-114LH	Gear Sleeve (LEFT HAND)
118	118-80	Stand Screws (4 Required)
149	149-45	Clamp Nut (2 Required)
183	183-114H-T	Frame, Full, Aluminum