



**Penn 115L-LH
9/0 Senator
Left Hand**

**PENN
REELS**

Penn Reel Parts list for:

Model: 115L-LH 9/0 Senator

KEY PART

NO	NO.	DESCRIPTION
1	1-115LH	LEFT SIDE PLATE (LEFT HAND)
2	2-115-0	SIDE PLATE RING-OUTER
2A	2-115-I	LEFT SIDE RING-INNER
3	3-115LH	BRIDGE W/ SLEEVE (LEFT HAND)
4	4-115	FIBER WASHER
5	5-115LH	MAIN GEAR (LEFT HAND)
6	6-115	DRAG WASHER (5 REQ.)
7	7c-115	METAL DRAG WASHER SET
8A	8-115	TENSION SPRING
9	9-114	SPACING SLEEVE
10	10-114	STAR DRAG WHEEL
11	11-115	ECCENTRIC JACK
12	12-114	PINION YOKE
13	13-114LH	PINION (LEFT HAND)
14	14-116	DOG SPRING
15	15-115	DOG
16	16-114	BRIDGE SCREW LOWER (2 REQ.)
17	17-114	BRIDGE SCREW UPPER (2 REQ.)
18	18-114	CLUTCH SPRING
19	19-115	ECCENTRIC
20	20-114	ECCENTRIC SPRING
21	21-114	ECCENTRIC LEVER
22	23-60	ECCENTRIC SCREW
23	23-116	HANDLE SCREW
23A	110-60	HANDLE LOCK SCREW
24	24-115	HANDLE
26	26-116	R.S. BEARING

KEY PART

NO	NO.	DESCRIPTION
27	27-115	RIGHT SIDE PLATE
28	28-115-I	RIGHT SIDE INNER
29	29L-115	SPOOL-ALUMINUM
30	30-115	STAND
31	39-12	R.S. STAND SCREW (3 REQ.)
32	32-21	R.S. STAND SCREW (3 REQ.)
33	33-340	ROD CLAMP
*	*33R-114	RINGED ROD CLAMP (OPTIONAL)
34	34-45	CLAMP SCREW (2 REQ.)
34C	34C-45	ROD CLAMP SCREW W/ NUTS
35	35-115	CLICK TONGUE
36	36-115	CLICK BUTTON
37	37-115	FRAME POST (5 REQ.)
38	39-13	R.S. POST SCREW (5 REQ.)
39	39-12	L.S. POST SCREW (5 REQ.)
40	40-114H	L.S. BEARING
54	54-114	HARNES LUG (4 REQ.)
56	56-116	ROD BRACE (ONLY)
56C	56C-115	ROD BRACE COMPLETE
98	98-114LH	GEAR SLEEVE (LEFT HAND)
99	99-115	HOOK SCREW L.H. THROW (2 REQ.)
136	136-115	PRESSURE PLATE WASHER
140	140-115	FELT WASHER
149	149-45	CLAMP NUT (2 REQ.)
149A	149-200	HEX NUT (2 REQ.)
155	155-115	TURN BUCKLE (2 REQ.)
165	165-115	HOOK SCREW R.H. THREAD (2 REQ.)

* Not Shown