



**PENN Senator Series
(14/0)
117L-LH Left Hand Version**

Penn Reel Parts list for:

Model: 117L-LH (14/0) Senator (LEFT Hand Model)

KEY PART NO.	NO.	DESCRIPTION	KEY PART NO.	NO.	DESCRIPTION
1	1-117LH	LEFT SIDE PLATE (LEFT HAND VERSION)	27	27-117	RIGHT SIDE PLATE
2	2-117-0	OUTER LEFT SIDE RING (2 REQ.)	29L	29L-117	SPOOL
2A	2-117-I	INNER PLATE SIDE RING (2 REQ.)	30	30-117	STAND
3	3-117LH	BRIDGE W/ SLEEVE (LEFT HAND VERSION)	31	39-12	LEFT/RIGHT SIDE STAND SCREW
4	4-117	FIBER WASHER	33	33-117	ROD CLAMP
5	5-117LH	MAIN GEAR (LEFT HAND VERSION)	*	*33R-117	RINGED ROD CLAMP (OPTIONAL)
6	6-117	DRAG WASHER (7 REQ.)	34	34-130	CLAMP SCREW
7C	7c-117	METAL DRAG WASHER SET	34C	34C-116	CLAMP SCREW W/ NUTS
8	8-117	TENSION SPRING	35	35-115	CLICK TONGUE
10	10-117	STAR DRAG WHEEL	36	36-117	CLICK BUTTON
11	11-116	ECCENTRIC JACK	37	37-116	FRAME POST (8 REQ.)
12	12-116	PINION YOKE	38	39-13	LEFT/RIGHT SIDE POST SCREW (8 REQ. PER SIDE)
13	13-117LH	PINION (LEFT HAND VERSION)	40	26-117	RIGHT SIDE BEARING
14	14-117	DOG SPRING	49	49-116	HANDLE SPACER
15	15-117	DOG	54	54-117	HARNES LUG (6 REQ.)
16	16-114	LOWER BRIDGE SCREW (2 REQ.)	56	56-117	ROD BRACE (2 REQ.)
17	17-114	UPPER BRIDGE SCREW (2 REQ.)	56C	56C-117	ROD BRACE (COMPLETE)
18	18-114	CLUTCH SPRINGS (2 REQ.)	56P	56P-117	ROD BRACE PAD
19	19-115	ECCENTRIC	86	86-118	BEVELED WASHER
20	20-114	ECCENTRIC SPRING	98	98-117LH	GEAR SLEEVE (LEFT HAND VERSION)
21	21-117	ECCENTRIC LEVER	99	99-116	HOOK SCREW L.H. THREAD (2 REQ.)
22	22-60	ECCENTRIC SCREW	149	149-116L	HEX NUT (2 REQ.)
23	23-116	HANDLE SCREW	149A	149-116H	CLAMP NUT (2 REQ.)
23A	110-60	HANDLE LOCK SCREW	155	155-116	TURN BUCKLE (2 REQ.)
24	24-117	HANDLE	156	156-117	DRAG COVER
26	26-117	LEFT SIDE BEARING	165	165-116	HOOK SCREW L.H. THREAD (4 REQ.)

* Not Shown