



TO ORDER: USE RD PREFIX  
WITH PART NUMBER

### PARTS LIST

| RD # | DESCRIPTION                   | RD # | DESCRIPTION               | RD # | DESCRIPTION                   |
|------|-------------------------------|------|---------------------------|------|-------------------------------|
| 0012 | Shaft Retainer Screw          | 1000 | Anti-Reverse Pawl Screw   | 3009 | Clutch Cam                    |
| 0113 | Tension Spring Washer "B"     | 1102 | Ball Bearing              | 3010 | Dial Retainer                 |
| 0244 | Ball Bearing                  | 1114 | Key Washer                | 3012 | BaitRunner Pawl Spring        |
| 0261 | Oscillating Slider            | 1116 | Eared Washer              | 3013 | BaitRunner Pawl Guide         |
| 0262 | "C" Lock                      | 1119 | Spool Washer              | 3016 | Click Gear                    |
| 0266 | "C" Lock                      | 1125 | Bail Spring Cover         | 3017 | Free Spool Tension Washer (B) |
| 0345 | Anti-Reverse Lever Screw      | 1126 | Bail Trip Cover           | 3018 | Eared Washer 'B's'            |
| 0476 | "E" Lock                      | 1174 | Handle Screw Cap          | 3019 | Free Spool Tension Screw      |
| 0540 | Pawl Guide Screw              | 1676 | Side Cover Screw (A)      | 3020 | Dial Spacer                   |
| 0543 | Side Cover Screw (B)          | 1677 | Bail Spring               | 3021 | BaitRunner Tension Dial       |
| 0642 | Clutch Plate Screw            | 2093 | Bail Assembly             | 3024 | Drag Washer                   |
| 0653 | Bearing Retainer Screw        | 2094 | Line Roller Spacer        | 3025 | Spool Assembly                |
| 0693 | Free Spool Tension Washer (A) | 2095 | Line Roller Bushing       | 3026 | Main Shaft                    |
| 0714 | Rotor Nut                     | 2096 | Line Roller Washer        | 3027 | Bail Trip Slide Cam           |
| 0720 | Bail Arm Screw                | 2097 | Line Roller Screw         | 3028 | Bail Trip Lever               |
| 0724 | Bail Arm                      | 2165 | Seal Plate                | 3029 | Body                          |
| 0727 | Line Roller                   | 2172 | Drag Knob                 | 3030 | Anti-Reverse Cam              |
| 0728 | Anti-Reverse Pawl Spring      | 2189 | Rotor                     | 3031 | Drive Gear                    |
| 0729 | Anti-Reverse Spring Holder    | 2193 | Handle Assembly           | 3032 | Drive Gear Spacer             |
| 0730 | Anti-Reverse Ratchet          | 2615 | BaitRunner Lever Screw    | 3033 | BaitRunner Ratchet            |
| 0731 | Bearing Retainer              | 2616 | Lock Washer               | 3034 | Ratchet Spacer                |
| 0732 | Pinion Gear                   | 2934 | Dial Click Screw          | 3035 | Side Cover                    |
| 0733 | Pinion Gear Bushing           | 2959 | Lever Shaft Retainer      | 3036 | BaitRunner Lever Arm (L)      |
| 0734 | Anti-Reverse Cam Spring       | 2963 | BaitRunner Click Spring   | 3037 | Clutch Plate Assembly         |
| 0737 | Anti-Reverse Pawl             | 2966 | Clutch Cam Spacer (B)     | 3038 | Clutch Cam Spacer (A)         |
| 0740 | Oscillating Gear Bushing      | 2981 | Free Spool Tension Spring | 3041 | BaitRunner Pawl               |
| 0741 | Oscillating Gear              | 2993 | Lever Spring              | 3042 | Dial Click                    |
| 0743 | Washer                        | 2994 | Pinion Spacer             | 3043 | Free Spool Tension Shaft      |
| 0787 | Nut Lock Screw                | 3002 | Clutch Spring             | 3044 | BaitRunner Lever Bridge       |
| 0819 | Anti-Reverse Lever            | 3003 | Clutch Pawl Spring        | 3045 | BaitRunner Lever Arm (R)      |
| 0958 | Bail Trip Cover Screw         | 3007 | Clutch Arm                | 3165 | Seal Plate Screw              |
|      |                               |      |                           | 3299 | Aluminum Spool                |