


JHX™ 4000F



Part No.	Description	Part No.	Description	Part No.	Description
RD 0026	Ball Bearing	RD 2852	Handle Screw Lock	RD 3871	Bushing Washer
RD 0041	Drive Gear Washer	RD 2934	Flange Screw	RD 3872	Anti-Reverse Pawl
RD 0071	Rotor Nut	RD 3359	Line Roller Washer	RD 3873	Anti-Reverse Pawl Spring
RD 0345	Anti-Reverse Lever Screw	RD 3449	Spool Assembly	RD 3874	Anti-Reverse Cam
RD 0543	Side Cover Screw (small)	RD 3503	Spool Washer	RD 3886	Bail Trip Lever
RD 0787	Nut Lock Screw	RD 3655	Cover Screw	RD 4351	Anti-Reverse Lever
RD 0792	Bearing Retainer Screw	RD 3665	Slider Retainer Screw	RD 4362	Side Cover Screw (large-silver)
RD 0940	Multi-Purpose Screw	RD 3676	Drag Knob	RD 4572	Bail Arm
RD 1008	Handle Lock Washer	RD 3677	Main Shaft	RD 5625	Line Roller Spacer
RD 1030	Handle Assembly	RD 3681	Bail Spring Guide (A)	RD 5628	Line Roller Collar
RD 1310	Line Roller Screw	RD 3682	Bail Spring	RD 5629	Line Roller Bushing
RD 1442	Handle Screw Cap	RD 3683	Bail Spring Guide (B)	RD 5630	Line Roller
RD 1506	Multi-Purpose Screw	RD 3690	Pinion Gear	RD 6797	Bail Spring Cover
RD 1511	Lever Spring	RD 3694	Drive Gear	RD 6798	Bail Assembly
RD 1520	Anti-Reverse Cam Spring	RD 3695	Oscillating Gear	RD 6799	Rotor
RD 1676	Side Cover Screw (large-black)	RD 3696	Oscillating Slider	RD 6800	Counterbalance Cover
RD 2293	Drive Gear Bushing	RD 3868	Lock Out Spring Holder	RD 6801	Body Assembly
RD 2516	Spool Support	RD 3869	Anti-Reverse Lock Out Spring	RD 6804	Sideplate Assembly
RD 2541	Anti-Reverse Pawl Screw	RD 3870	Anti-Reverse Lock Out		