


SHIMANO®

SAHARA™

SH-2000FA



Part No.	Description	Part No.	Description	Part No.	Description
RD 0026	Ball Bearing	RD 4656	Trip Lever Spacer	RD 6628	Oscillating Slider
RD 0041	Drive Gear Washer	RD 4658	Clutch Cover Screw	RD 6679	Nut Retainer
RD 0050	Anti-Reverse Lever Screw	RD 4659	Roller Clutch Assembly	RD 6680	Rotor Support Bushing
RD 0071	Rotor Nut	RD 4661	Anti-Reverse Cam Ring	RD 6686	Click Spring
RD 0642	Side Cover Screw (long)	RD 4749	Bail Arm Screw	RD 6687	Bail Arm Click
RD 0806	Bail Hold Support Screw	RD 4798	Roller Clutch Screw	RD 6692	Bail Hold Support Shaft
RD 0930	Ball Bearing	RD 5180	Drag Knob	RD 6694	Bail Hold Support Spacer
RD 1008	Handle Lock Washer	RD 5189	Anti-Reverse Cam	RD 6696	Pinion Gear
RD 1083	Slider Retainer Screw	RD 5190	Anti-Reverse Lever	RD 6697	Friction Ring Screw
RD 1427	Spool Support	RD 5547	Handle Assembly	RD 6698	Friction Ring
RD 1520	Anti-Reverse Cam Spring	RD 5625	Line Roller Spacer	RD 6699	Drive Gear
RD 2852	Handle Screw Lock	RD 5628	Line Roller Collar	RD 6702	Spool Assembly
RD 3309	Line Roller Screw	RD 5629	Line Roller Bushing	RD 6703	Line Roller Washer
RD 3402	Rotor Protector Screw (small)	RD 5630	Line Roller	RD 6704	Bail Spring Guide (B)
RD 3455	Spool Washer	RD 6289	Nut Retainer Screw	RD 6705	Bail Arm
RD 3673	Oscillating Gear	RD 6297	Bail Spring Guide (A)	RD 6706	Bail Trip Lever
RD 4640	Bail Spring	RD 6482	Rotor Protector Screw (large)	RD 6707	Bail Assembly
RD 4652	Lever Spring Guide (B)	RD 6596	Side Cover Screw (short)	RD 6708	Body Assembly
RD 4653	Lever Spring	RD 6621	Main Shaft	RD 6709	Rotor Assembly
RD 4654	Lever Spring Guide (A)	RD 6627	Handle Screw Cap		