


SHIMANO®

SLADE

SL-5000F



Part No.	Description	Part No.	Description	Part No.	Description
RD 0244	Ball Bearing	RD 2571	Bail Arm Screw	RD 4000	Anti-Reverse Pawl
RD 0345	Anti-Reverse Lever Screw	RD 2722	Counterbalance Cover Screw	RD 4001	Anti-Reverse Pawl Spring
RD 0521	Rotor Nut	RD 3182	Spool Support	RD 4002	Anti-Reverse Cam
RD 0690	Drive Gear Washer	RD 3195	Bushing	RD 4005	Drive Gear
RD 0787	Nut Lock Screw	RD 3202	Anti-Reverse Lever	RD 4007	Oscillating Gear
RD 0940	Bail Hold Support Screw	RD 3204	Ball Bearing	RD 4008	Oscillating Slider
RD 1008	Handle Lock Washer	RD 3359	Line Roller Washer	RD 4581	Bail Arm
RD 1109	Slider Retainer Screw	RD 3987	Drag Knob	RD 4627	Side Cover Screw (large-silver)
RD 1310	Line Roller Screw	RD 3989	Main Shaft	RD 5625	Line Roller Spacer
RD 1511	Lever Spring	RD 3990	Spool Washer	RD 5628	Line Roller Collar
RD 1520	Anti-Reverse Cam Spring	RD 3993	Bail Spring Cover	RD 5629	Line Roller Bushing
RD 1863	Handle Screw Cap	RD 3994	Bail Trip Lever	RD 5642	Line Roller
RD 2342	Side Cover Screw (large-black)	RD 3995	Counterbalance Cover	RD 6776	Oscillating Gear Bushing
RD 2530	Bail Spring Cover Screw	RD 3996	Anti-Reverse Lock Out	RD 6815	Bail Assembly
RD 2532	Bail Spring Guide (A)	RD 3997	Anti-Reverse Lock Out Spring	RD 6819	Handle Assembly
RD 2533	Bail Spring	RD 3998	Lock Out Spring Holder	RD 6834	Spool Assembly
RD 2534	Bail Spring Guide (B)	RD 3999	Bearing Retainer Screw	RD 6835	Rotor
RD 2541	Anti-Reverse Pawl Screw			RD 6836	Body Assembly
RD 2548	Side Cover Screw (small)				