



SOLSTACE 3000R 91

TO ORDER: USE RD PREFIX
WITH PART NUMBER

PARTS LIST

| RD # | DESCRIPTION | RD # | DESCRIPTION | RD # | DESCRIPTION |
|------|--------------------------------|------|------------------------------|------|-----------------------------|
| 0026 | Ball Bearing | 1596 | Bushing Washer | 2337 | Worm Shaft Spacer |
| 0041 | Drive Gear Washer | 1712 | Anti-Reverse Pawl Screw | 2339 | Worm Shaft |
| 0071 | Rotor Nut | 1888 | Anti-Reverse Lock Out Spring | 2340 | Drive Gear |
| 0345 | Anti-Reverse Lever Screw | 1890 | Bushing Washer | 2342 | Side Cover Screw (A) |
| 0540 | Bearing Retainer Screw | 1932 | Anti-Reverse Pawl Spring | 2343 | Oscillating Slider Retainer |
| 0543 | Side Cover Screw (B) | 2016 | Drag Washer "H2" (white) | 2344 | Oscillating Slider |
| 0579 | Eared Washer "B" | 2017 | Drag Coil Spring | 2346 | Drag Washer "C2" (white) |
| 0582 | "O" Ring | 2048 | Line Roller Washer | 2347 | Click Gear |
| 0584 | Hold Click Spring | 2257 | Drag Washer "H1" | 2348 | Drag Washer "C1" |
| 0586 | Fightin' Pressure Screw Washer | 2288 | Worm Bearing (rear) | 2349 | Eared Washer "BF" |
| 0589 | Lever Hold Spring | 2292 | Anti-Reverse Lever | 2350 | Drag Shaft |
| 0774 | Handle Knob Screw | 2293 | Drive Gear Bushing | 2351 | Drag Spring Washer |
| 0787 | Nut Lock Screw | 2298 | Spacer | 2352 | Pressure Screw |
| 0833 | Handle Knob | 2299 | Oscillating Slider Bushing | 2353 | Drag Programmer Screw |
| 0930 | Ball Bearing | 2300 | Oscillating Pawl | 2394 | Bail Trip Lever |
| 0940 | Bail Trip Cam Screw | 2309 | Slider Retainer Screw | 2852 | Handle Screw Lock |
| 0949 | Trigger Screw | 2320 | Quick-Fire II Trigger | 2860 | Bail Spring Guide (A) |
| 1008 | Handle Lock Washer | 2321 | Rotor Side Cover | 2861 | Trigger Cam |
| 1302 | Line Roller Screw | 2323 | Line Roller Bushing | 2862 | Bail Arm |
| 1366 | Drag Click | 2324 | Bail Spring Guide (B) | 2908 | Spool Assembly |
| 1370 | Lever Click Gear | 2325 | Sic Ceramic Roller | 3102 | Handle Assembly |
| 1371 | Fightin' Pressure Screw | 2329 | Bail Trip Lever Screw | 3112 | Rotor |
| 1373 | Drag Programmer | 2330 | Anti-Reverse Ratchet | 3114 | Bail Spring Cover |
| 1401 | Fightin' Pressure Screw | 2331 | Anti-Reverse Lock Out | 3125 | Drag Click Screw |
| 1442 | Handle Screw Cap | 2332 | Bearing Retainer | 3130 | Main Shaft |
| 1506 | Multi-Purpose Screw | 2333 | Pinion Gear | 3142 | Bail Assembly |
| 1509 | Bail Spring | 2334 | Anti-Reverse Pawl | 3143 | Idle Gear |
| 1511 | Lever Spring | 2335 | Anti-Reverse Cam | 3144 | Side Cover |
| 1520 | Anti-Reverse Cam Spring | 2336 | Worm Bearing (front) | 3145 | Body |