

## SR-4000R

PART #	DESCRIPTION	"A" INTERCHANGEABILITY	"B" INTERCHANGEABILITY
RD 0026	Ball Bearing	BNT0807, BR 0037, KXB0028, MLX0025, TGT0223, TLD0123, TT 0117	
RD 0041	Drive Gear Washer	BR 0049, RD 1524, MLX0040, X/Z0150	
RD 0071	Rotor Nut	BR 0010, KXB0073, MLX0068	
RD 0540	Multi Purpose Screw	BNT0888, BR 0088, MCR0021, TGT0088, TLD0056, TT 0187	BR 0470, BR 0539, RD 1508, RD 3088
RD 0579	Eared Washer "B"	BR 0839	
RD 0586	Fightin' Pressure Screw Washer		
RD 0787	Nut Lock Screw	BNT0888, BR 0278	RD 1111
RD 0792	Bearing Retainer Screw		
RD 0830	Ball Bearing	BR 0047	
RD 1370	Lever Click Gear		
RD 1371	Fightin' Pressure Screw		
RD 1511	Lever Spring		
RD 1520	Anti-Reverse Cam Spring		
RD 1888	Anti-Reverse Lock Out Spring		
RD 2016	Drag Washer "F" (cloth)	BR 0840	
RD 2017	Drag Coil Spring		
RD 2257	Drag Washer "F" (blue)		
RD 2346	Drag Washer "C" (cloth)	BR 0838	
RD 2347	Click Gear		
RD 2348	Drag Washer "C" (blue)		
RD 2349	Eared Washer "B"		
RD 2350	Drag Shaft		
RD 2351	Drag Spring Washer		
RD 2541	Anti-Reverse Pawl Screw		
RD 3125	Drag Click Screw		
RD 3402	Cover Screw		RD 3655
RD 3406	Handle Screw Cap Assembly		RD 3688
RD 3416	Quick-Fire II Trigger Assembly		RD 3879
RD 3443	Spool Assembly (aluminum)		
RD 3446	Spool Assembly (graphite)		RD 3882
RD 3681	Ball Spring Guide (A)		
RD 3683	Ball Spring Guide (B)		
RD 3685	Ball Trip Lever		
RD 3687	Anti-Reverse Ratchet		
RD 3688	Anti-Reverse Lock Out		
RD 3689	Bushing Washer		
RD 3691	Anti-Reverse Pawl		
RD 3692	Anti-Reverse Pawl Spring		
RD 3693	Anti-Reverse Cam		
RD 3694	Driver Gear		
RD 3695	Oscillating Gear		
RD 3720	Line Roller		
RD 3731	Rotor		RD 3878, RD 3710
RD 3732	Ball Assembly		
RD 3733	Ball Spring		
RD 3734	Ball Spring Cover		RD 3884, RD 3712
RD 3735	Counterbalance Cover		RD 3886, RD 3713
RD 3738	Double Paddle Handle Assembly		RD 3878
RD 3741	Anti-Reverse Lever Assembly		
RD 3747	Slider Retainer Screw		
RD 3762	Main Shaft		
RD 3763	Pinion Gear		
RD 3764	Hold Click Spring		
RD 3765	Drag Click		
RD 3766	Oscillating Slider		
RD 3767	Oscillating Slider Retainer		
RD 3768	Drag Programmer Spacere		
RD 3790	Pressure Screw Assembly		
RD 3791	Fightin' Drag Lever		RD 3899
RD 3792	Lever Hold Spring		
RD 3793	Drag Programmer		RD 3800
RD 3794	Drag Programmer Screw		RD 2458
RD 3795	Slide Cover Screw		RD 3897, RD 3714, RD 3736, RD 3770, RD 3878
RD 3796	Body Assembly		