


# SHIMANO

STRADIC

A-RB

ST-5000FI



Part No.	Description	Part No.	Description	Part No.	Description
RD 0071	Rotor Nut	RD 8999	Click Pin	RD10435	Worm Shaft
RD 0787	Screw	RD 9005	Roller Clutch Assembly	RD10438	Oscillating Pawl Cover
RD 1520	Anti-Reverse Cam Spring	RD 9092	Screw	RD10439	Oscillating Slider
RD 2298	Spacer	RD 9121	Bushing	RD10442	Worm Shaft Retainer
RD 2409	Spacer	RD 9872	Screw	RD10443	Oscillating Guide
RD 3177	Key Washer	RD 9975	Oscillating Slider Bushing	RD10444	Screw
RD 3503	Spool Washer	RD10306	Drag Click Collar	RD10445	Screw
RD 4749	Screw	RD10314	Ball Bearing	RD10576	Screw
RD 4777	Screw	RD10320	Ball Bearing	RD10585	Click Spring
RD 4829	Screw	RD10345	Drag Washer	RD10746	Oscillating Guide B
RD 5690	Screw	RD10352	Spool Support	RD10752	Spring Guide A Support
RD 5947	Screw	RD10381	Handle Screw Cap	RD10753	Bail Spring
RD 6010	Screw	RD10385	Key Washer	RD10754	Bail Trip Cover
RD 6265	Screw	RD10397	Ball Bearing	RD10756	Bail Spring Seat
RD 6482	Screw	RD10406	Anti-Reverse Lever	RD11137	Bail Assembly
RD 6524	Worm Bushing (rear)	RD10415	Drag Washers Retainer	RD11146	Washer
RD 7787	Bail Spring Guide A	RD10416	Eared Washer	RD11425	Handle Knob I.D. Plate
RD 7857	Oscillating Pawl	RD10417	Drag Click	RD11465	Handle Knob Shaft Collar
RD 7875	Oil Cap	RD10419	Main Shaft	RD11816	Pinion Gear
RD 7923	Bail Trip Lever	RD10420	Bearing Spacer	RD11817	Drive Gear
RD 7926	Screw	RD10421	Line Roller Collar	RD11821	Rear Protector
RD 7927	Washer	RD10422	Line Roller	RD11838	Drag Knob
RD 7944	Bail Trip Strike	RD10423	Line Roller Bushing	RD11839	Spool Assembly
RD 7945	Nut	RD10424	Ball Bearing	RD11841	Bail Arm
RD 8147	Friction Ring	RD10427	Bail Hold Support Guard	RD11842	Rotor
RD 8170	Handle Knob	RD10429	Line Roller Support	RD11843	Side Cover
RD 8171	Washer	RD10431	Anti-Reverse Cam	RD11844	Handle Shank Assembly
RD 8172	Handle Knob Nut	RD10432	Anti-Reverse Lever Cover	RD11845	Handle Assembly
RD 8579	Bail Spring Cover	RD10433	Worm Bushing (front)	RD11846	Body
RD 8758	Click Spring	RD10434	Idle Gear		