



SYMETRE 1000F⁹¹

TO ORDER: USE RD PREFIX
WITH PART NUMBER

PARTS LIST

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0041	Drive Gear Washer	2271	Quick Fire II Trigger	2858	Bail Arm
0071	Rotor Nut	2272	Rotor Side Cover	2876	Bearing Retainer
0345	Anti-Reverse Lever Screw	2275	Bail Spring Guide (B)	2877	Idle Gear (B) Shaft
0773	Handle Knob	2278	Bail Trip Lever	2878	Worm Bearing
0774	Handle Knob Screw	2279	Anti-Reverse Ratchet	2879	Worm Shaft Spacer
0784	Line Roller Washer	2280	Anti-Reverse Lock Out	2881	Worm Shaft
0787	Nut Lock Screw	2283	Anti-Reverse Pawl Screw	2883	Oscillating Pawl Cover
0930	Ball Bearing	2284	Anti-Reverse Pawl	2884	Oscillating Slider
0949	Trigger Screw	2285	Anti-Reverse Pawl Spring	2901	Spool Assembly
1008	Handle Lock Washer	2286	Anti-Reverse Cam	3047	Key Washer
1021	Handle Assembly	2287	Anti-Reverse Cam Spring	3048	Drag Washer
1038	SiC Ceramic Roller	2292	Anti-Reverse Lever	3057	Idle Gear (A)
1302	Line Roller Screw	2296	Slider Retainer Screw	3059	Idle Gear (B)
1426	Spool Washer	2298	Spacer	3061	Side Cover Screw
1427	Spool Support	2299	Oscillating Slider Bushing	3084	Drag Knob
1442	Handle Screw Cap	2300	Oscillating Pawl	3085	Rotor
1504	Bail Spring Cover Screw	2387	Pinion Gear	3086	Bail Assembly
1506	Bail Trip Lever Screw	2391	Drive Gear	3087	Bail Trip Cam Screw
1509	Bail Spring	2446	Bushing	3088	Bail Arm Screw
1888	Anti-Reverse Lock Out Spring	2707	Drag Washers Retainer	3089	Bail Spring Cover
1890	Bushing Washer	2852	Handle Screw Lock	3090	Side Cover
1891	Bearing Retainer Screw	2856	Bail Spring Guide (A)	3091	Body
2269	Main Shaft	2857	Trigger Cam		