

| PART # | DESCRIPTION | *A* INTERCHANGEABILITY | *B* INTERCHANGEABILITY |
|---------|--------------------------------|--|------------------------|
| RD 0026 | Ball Bearing | BNT0807, BR 0037, IXXB0028, MLX0025, TGT0223, TLD0123, TT 0117 | |
| RD 0041 | Drive Gear Washer | BR 0049, RD 1524, IXXB0040, X/Z0150. | |
| RD 0071 | Rotor Nut | BR 0010, IXXB0073, MLX0098. | |
| RD 0540 | Multi-Purpose Screw | BNT0689, BR 0066, MCR0021, BR 0470, BR 0539, TGT0068, TLD0056, TT 0187, RD 1506, RD 3088 | |
| RD 0787 | Nut Lock Screw | BNT0696, BR 0278. | RD 1111. |
| RD 0930 | Ball Bearing | BR 0047. | |
| RD 1511 | Lever Spring | | |
| RD 1520 | Anti-Reverse Cam Spring | | |
| RD 1596 | Bushing Washer | | |
| RD 1712 | Anti-Reverse Pawl Screw | | |
| RD 1888 | Anti-Reverse Lock Out Spring | | |
| RD 1890 | Bushing Washer | TGT0224. | |
| RD 1932 | Anti-Reverse Pawl Spring | | |
| RD 2296 | Slider Retainer Screw | BR 0511. | |
| RD 2298 | Spacer | BR 0513. | |
| RD 2299 | Oscillating Slider Bushing | BR 0514. | |
| RD 2300 | Oscillating Pawl | BR 0515. | |
| RD 2330 | Anti-Reverse Ratchet | | |
| RD 2331 | Anti-Reverse Lock Out | | |
| RD 2332 | Bearing Retainer | | |
| RD 2334 | Anti-Reverse Pawl | | |
| RD 2335 | Anti-Reverse Cam | | |
| RD 2360 | Main Shaft | | |
| RD 2361 | Spool Washer | BR 0531. | |
| RD 2362 | Spool Support | BR 0532. | |
| RD 2394 | Ball Trip Lever | | |
| RD 2404 | Idle Gear Retainer | BB 0052, BNT0686, RD 0189, BR 0022, BR 0481, TGT0062, TLD0018, TRN0043, TRN0090, TT 0069 | |
| RD 2406 | Drive Gear | | |
| RD 2409 | Worm Shaft Spacer | | |
| RD 2864 | Pinion Idle Gear Washer | | |
| RD 2865 | Pinion Idle Gear | | |
| RD 2866 | Pinion Gear | | |
| RD 2867 | Bushing | | |
| RD 2868 | Worm Bearing | | |
| RD 2869 | Idle Gear | | |
| RD 2870 | Worm Shaft | | |
| RD 2871 | Worm Shaft Retainer | | |
| RD 2872 | Oscillating Pawl Cover | | |
| RD 2873 | Oscillating Slider | | |
| RD 2904 | Spool Assembly | | RD 2359. |
| RD 3305 | SiC Ceramic Roller | | |
| RD 3402 | Cover Screw | | RD 3655. |
| RD 3403 | Anti-Reverse Lever Assembly | | RD 3826. |
| RD 3406 | Handle Screw Cap Assembly | | RD 3668. |
| RD 3414 | Drag Knob | | RD 3501, RD 3676. |
| RD 3415 | Rotor | | |
| RD 3416 | Quick-Fire II Trigger Assembly | | RD 3679. |
| RD 3417 | Bail Assembly | | |
| RD 3418 | Bail Spring Guide (A) | | |
| RD 3419 | Bail Spring | | |
| RD 3420 | Bail Spring Guide (B) | | |
| RD 3421 | Bail Spring Cover | | |
| RD 3422 | Counterbalance Cover | | |
| RD 3423 | Side Cover Screws | | |
| RD 3424 | Body Assembly | | |
| RD 3425 | Handle Assembly | | |