



SYMETRE 4000RH 01

| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|--------|--------------------------|--------|--------------------------------|--------|----------------------------|
| 0026 | Ball Bearing | 5222 | Idle Gear Lock | 6330 | Line Roller Bushing |
| 0041 | Drive Gear Washer | 5253 | Oscillating Guide | 6331 | Line Roller Spacer |
| 0050 | Anti-Reverse Lever Screw | 5255 | Worm Shaft | 6332 | Line Roller Washer |
| 0071 | Rotor Nut | 5256 | Idle Gear | 6353 | Bail Spring Guide (A) |
| 0589 | Lever Hold Spring | 5257 | Oscillating Guide Retainer | 6354 | Bail Spring |
| 0806 | Bail Hold Support Screw | 5258 | Anti-Reverse Lever | 6355 | Bail Spring Guide (B) |
| 0930 | Ball Bearing | 5261 | Slider Retainer Screw | 6358 | Rotor Protector |
| 1008 | Handle Lock Washer | 5262 | Oscillating Slider Retainer | 6359 | Bail Trip Lever |
| 1506 | Clutch Cover Screw | 5263 | Oscillating Slider | 6482 | Protector Screw (large) |
| 1520 | Anti-Reverse Cam Spring | 5264 | Eared Washer OB rO | 6483 | Bail Hold Support Spacer |
| 2094 | Spacer | 5266 | Drag Washer OHÓ (cloth) | 6499 | Side Cover Screw (small) |
| 2298 | Spacer | 5269 | Drag Washer OHÓ (blue) | 6517 | Bail Assembly |
| 2346 | Drag Washer OCÓ (cloth) | 5270 | Eared Washer OBÓ | 6525 | Drive Gear |
| 2347 | Click Gear | 5275 | Hold Click Spring | 6529 | Side Cover Screw (medium) |
| 2348 | Drag Washer OCÓ (blue) | 5276 | Lever Click Gear | 6581 | Bail Spring Cover |
| 2409 | Worm Shaft Spacer | 5277 | FightinÓ Pressure Screw Washer | 6582 | Rotor |
| 2852 | Handle Screw Lock | 5278 | FightinÓ Pressure Screw | 6674 | Bail Arm |
| 3081 | Side Cover Screw (long) | 5310 | Bushing | 6894 | Oscillating Slider Bushing |
| 3282 | Roller Clutch Screw | 5338 | Drag Washer OCÓ (cloth) | 6919 | Roller Clutch Assembly |
| 3306 | Ball Bearing | 5339 | Drag Shaft (B) | 6920 | Spacer |
| 3309 | Line Roller Screw | 5340 | Key Washer OAÓ | 6922 | Worm Bushing |
| 3402 | Protector Screw (small) | 5341 | Drag Coil Spring | 6924 | Anti-Reverse Cam |
| 3436 | Drag Programmer Screw | 5342 | Drag Spring Washer | 6927 | Rear Cover Screw (long) |
| 4150 | Rear Cover Screw (short) | 5343 | Pressure Screw | 6932 | Drag Shaft (A) |
| 4421 | Handle Screw Cap | 5344 | Hold Click Spring Washer | 6937 | Main Shaft |
| 4460 | Handle Assembly | 5880 | Nut Lock Screw | 6979 | Spool Assembly (aluminum) |
| 4652 | Lever Spring Guide (B) | 6077 | Click Pin | 6980 | Spool Assembly (graphite) |
| 4653 | Lever Spring | 6085 | Line Roller | 6982 | Side Cover Assembly |
| 4654 | Lever Spring Guide (A) | 6132 | Friction Ring | 6983 | Body |
| 4656 | Trip Lever Spacer | 6290 | Rotor Nut Lock Plate | 6984 | Rear Cover |
| 4678 | Oscillating Pawl | 6296 | Click Spring | 6985 | FightinÓ Drag II Lever |
| 4749 | Bail Arm Screw | 6307 | Bail Hold Support Shaft | 6986 | Drag Programmer |
| 4838 | Drive Gear Bushing | 6329 | Bearing Spacer | 7287 | Pinion Gear |