



Part No.	Description	Part No.	Description	Part No.	Description
RD 0013	Lever Spring	RD 0940	Multi-Purpose Screw	RD 1883A	Anti-Reverse Lock Out
RD 0018	Line Roller	RD 0948	Multi Purpose Screw	RD 1884A	Anti-Reverse Lock Out Spring
RD 0026	Ball Bearing	RD 1008	Handle Lock Washer	RD 1885A	Pinion Spacer
RD 0041	Drive Gear Washer	RD 1083	Slider Retainer Screw	RD 1886	Bail Trip Lever Screw
RD 0049	Lock Washer	RD 1302	Line Roller Screw	RD 1927	Spool Washer
RD 0053	Anti-Reverse Cam Spring	RD 1418	Drag Knob	RD 2852	Handle Screw Lock
RD 0071	Rotor Nut	RD 1427	Spool Support	RD 4142	Spool Assembly
RD 0345	Anti-Reverse Lever Screw	RD 1432	Bail Arm	RD 4144	Main Shaft
RD 0539	Anti-Reverse Pawl Spring	RD 1437	Pinion Gear	RD 4146	Bail Trip Lever
RD 0540	Anti-Reverse Pawl Screw	RD 1438	Anti-Reverse Pawl	RD 4158	Bail Spring
RD 0543	Side Cover Screw	RD 1439	Drive Gear	RD 4159	Oscillating Spacer
RD 0784	Line Roller Washer	RD 1440	Oscillating Arm	RD 4252	Bail Trip Cover
RD 0787	Nut Lock Screw	RD 1442	Handle Screw Cap	RD 4253	Bail Spring Cover
RD 0792	Bearing Retainer Screw	RD 1443	Oscillating Block	RD 4254	Bail Spring Cover Screw
RD 0795	Bushing B	RD 1444	Anti-Reverse Cam	RD 4345	Bail Assembly
RD 0884	Anti-Reverse Ratchet	RD 1445	Anti-Reverse Lever	RD 7105	Body Assembly
RD 0930	Ball Bearing	RD 1446	Handle Assembly	RD 7243	Rotor