



# SHIMANO®

## 1989 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.  
Irvine, CA 92718



1989 Model



### EXPLODED PARTS VIEW

Bantam EXTRA HIGH SPEED 5:1 GEAR RATIO  
**Bass One Mag**  
RIGHT HANDLE CRANK

### PARTS LIST

#### PART # DESCRIPTION

BNT 0015 Drag Spring Washer  
BNT 0016 Friction Washer (C)  
BNT 0042 Line Guide Pawl  
BNT 0133 Worm Shaft Retainer  
BNT 0151 Pawl Cap  
BNT 0184 Magnet Retainer Lock  
BNT 0291 Side Plate Screw  
BNT 0425 Clutchbutton Lock  
BNT 0604 Yoke Spring  
BNT 0612 Anti-Reverse Pawl Pin  
BNT 0660 Spring Spacer  
BNT 0661 Magnet Retainer Spring  
BNT 0664 Spacer (B)  
BNT 0706 Magnet Retainer  
BNT 0766 Dial Friction Washer  
BNT 0795 Handle Nut Plate Screw  
BNT 0796 Handle Nut Plate  
BNT 0797 Handle Nut  
BNT 0799 Friction Washer  
BNT 0801 Cast Control Cap  
BNT 0802 Spool Tension Spacer (B)

#### PART # DESCRIPTION

BNT 0803 Spool Tension Spacer (A)  
BNT 0804 Spool Tension Spring  
BNT 0805 Spool Shaft Bushing (A)  
BNT 0807 Drive Shaft Bearing  
BNT 0808 Friction Washer (B)  
BNT 0809 Key Washer (A)  
BNT 0810 Drag Washer (A)  
BNT 0811 Drive Gear  
BNT 0812 Drag Washer (B)  
BNT 0813 Key Washer (B)  
BNT 0814 Anti-Reverse Ratchet  
BNT 0815 Drive Shaft  
BNT 0816 Drive Shaft Washer  
BNT 0817 Multi Purpose Screw  
BNT 0818 Drive Shaft Retainer  
BNT 0819 Drive Shaft Bushing  
BNT 0820 Pinion Gear  
BNT 0821 Yoke  
BNT 0822 Retractor Spring Pin  
BNT 0823 Retractor Spring  
BNT 0824 Yoke Plate Washer (B)

#### PART # DESCRIPTION

BNT 0825 Yoke Plate Washer (A)  
BNT 0826 Clutch Button  
BNT 0827 Worm Shaft  
BNT 0828 Worm Bearing  
BNT 0829 Anti-Reverse Pawl  
BNT 0830 Spacer (Optional)  
BNT 0834 Level Wind Guard  
BNT 0835 Spool Shaft Bushing (B)  
BNT 0836 Spool  
BNT 0837 Dial Case  
BNT 0838 Magnetic Control Dial  
BNT 0840 Left Side Plate Screw  
BNT 0853 Handle Assembly  
BNT 0875 Star Drag  
BNT 0876 Right Side Plate  
BNT 0877 Line Guide  
BNT 0878 Level Wind Protector  
BNT 0879 One-Piece Frame  
BNT 0880 Spool Shaft Bushing (C)  
BNT 0881 Left Side Plate