



SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

TO ORDER:

This reel belongs to the "Bantam" series.
Please order parts using the abbreviation
"BNT" and the part number.



EXPLODED PARTS VIEW BGX 1550

PARTS LIST

PART # DESCRIPTION

- 1. Handle Nut Plate Screw
- 2. Handle Nut
- 6. Friction Washer "A"
- 9. Cast Control Spacer
- 11. Right Side Plate Screw
- 14. Friction Washer "B"
- 15. Drag Spring Washer
- 16. Friction Washer "C"
- 32. Bearing Retainer
- 36. Stabilizer Bar Screw "A"
- 40. Level Wind Guard
- 42. Line Guide Pawl
- 44. Stabilizer Bar
- 45. Worm Bearing "B"
- 60. Spacer (optional)
- 133. Worm Shaft Retainer
- 151. Pawl Cap
- 162. Drive Shaft Retainer
- 170. Anti-Reverse Pawl
- 184. Magnet Retainer Lock
- 188. O Ring
- 191. Left Side Plate Screw
- 192. Stabilizer Bar Screw "B"

PART # DESCRIPTION

- 244. Bushing "B"
- 265. Spacer (optional)
- 268. Drive Shaft Washer "A"
- 277. Bearing Spacer "B"
- 311. Magnet Retainer
- 330. Handle Nut Plate
- 335. Bearing Washer "A"
- 340. Switch Spring
- 341. Switch Spring Lock
- 345. Drive Shaft Washer "B"
- 352. Yoke
- 354. Retractor Spring
- 356. Worm Bearing "A"
- 357. Line Guide
- 365. Magnetic Control Dial
- 398. Anti-Reverse Switch
- 405. Retractor Guide
- 423. Yoke Spring
- 458. Bushing "A"
- 459. Retractor Guide Screw
- 463. Spool
- 464. Bearing Spacer

PART # DESCRIPTION

- 467. Worm Shaft
- 470. Bushing "C"
- 483. Handle Assembly
- 484. Star Drag
- 486. Right Side Plate Cover
- 487. Cast Control Cap
- 488. Clutch Button Attachment
- 489. Key Washer "A"
- 490. Drag Washer
- 491. Drive Gear
- 492. Key Washer "B"
- 493. Anti-Reverse Ratchet
- 494. Drive Shaft
- 495. Idle Gear
- 496. Drive Shaft Washer "C"
- 497. Pinion Gear
- 502. Level Wind Protector
- 523. Right Side Plate
- 524. Set Plate Assembly
- 525. Frame
- 526. Left Side Plate
- 527. Thumb Rest