



CARDIFF
401A ARB
ARB

(1RH532401U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0001	Screw	1965	Idle Gear A	2646	Stabilizer Bar
0011	Screw	1969	Idle Gear B	2648	Idle Gear A Bush
0032	Bearing Retainer	1976	Click Shaft	2649	Screw
0042	Line Guide Pawl	2050	Clutch Cam Retainer	2650	Clutch Button Support Bar
0133	E Lock	2077	Yoke	2652	Screw
0188	O Ring	2078	Retractor Spring	2653	Idle Gear B Shaft
0425	E Lock	2081	Clutch Pawl Spring	2654	Worm Shaft
0664	Spacer B	2083	Clutch Plate	2655	Click Spring
0686	E Lock	2092	Click Plate	2773	Drive Gear
0799	Friction Washer	2093	Click Switch Spring	2774	Drive Shaft
0816	Washer	2095	Click Pawl	2775	Pinion Gear
0830	Space	2224	Spool Tension Spacer A	2927	Ball Bearing
1133	Yoke Spring	2238	Screw	2929	Ball Bearing
1201	Retractor Spring Collar	2267	Worm Bushing B	3095	Handle Assembly
1227	Push Nut (SPN-2)	2327	Return Pin Guide	3097	Roller Clutch Inner Tube
1245	Spacer	2330	Clutch Cam	3098	Side Plate Nut
1354	Screw	2331	Clutch Pawl	3102	Spool Assembly
1455	Drag Spring Washer H	2470	Handle Nut Plate	3107	Line Guide
1472	Anti-Reverse Pawl	2476	Cast Control Cap	3110	Side I.D. Plate
1560	Pawl Cap	2511	Washer	3111	Star Drag
1613	Drag Spring Washer L	2512	Screw	3112	Left Side Plate
1616	Screw	2514	O Ring	3113	Roller Clutch Assembly
1618	Key Washer C	2516	Drag Washer AG	3114	Set Plate
1620	Eared Washer	2517	Drag Washer CG	3115	Clutch Button Guide A
1672	E Lock	2518	Drag Washer BG	3116	Clutch Button Guide B
1696	Cast Control Spacer B	2520	Drive Shaft Washer B	3117	Quick-Fire II Clutch Bar
1853	Key Washer A	2547	Handle Nut	3118	One-Piece Frame
1927	Anti-Reverse Ratchet	2575	Brake Collar	3119	Click Switch
1930	Screw	2644	Worm Bushing A	3120	Right Side Plate
1949	Screw	2645	Level Wind Guard	3130	Washer

(160818)