


TRINIDAD TN 50 02



Part No.	Description	Part No.	Description	Part No.	Description
TGT0058	Spacer "B"	TGT0333	Click Spring	TGT0451	Yoke
TGT0062	Click Pawl Retainer	TGT0334	Click Spring Holder	TGT0452	Pinion Gear
TGT0065	Spacer (A)	TGT0335	"BR" Click Spring	TGT0453	Yoke Plate
TGT0111	Drive Shaft Retainer	TGT0336	"BR" Click Pin	TGT0454	Set Plate Screw (B)
TGT0128	Handle Nut Plate Screw	TGT0338	"BR" Washer (D)	TGT0455	Anti-Reverse Pawl Keeper
TGT0182	Cast Control Spacer (A)	TGT0348	Spacer (C)	TGT0456	Set Plate
TGT0271	Ball Bearing	TGT0360	Drive Shaft Washer (B)	TGT0457	Set Plate Screw (A)
TGT0274	Right Side Plate Screw (A)	TGT0424	Handle Nut Plate	TGT0458	Ball Bearing
TGT0277	Cast Control Spacer (B)	TGT0425	Handle Nut	TGT0459	Drive Shaft Washer (A)
TGT0279	Smoother	TGT0426	Handle Assembly	TGT0462	Click Gear
TGT0281	Roller Clutch Bearing	TGT0427	Drive Shaft Shield	TGT0463	"BR" Gear (A)
TGT0282	Eccentric Cam Bushing	TGT0428	Star Drag	TGT0464	Click Gear Retainer
TGT0283	Clutch Spring	TGT0429	Star Drag Washer	TGT0465	Bearing Retainer
TGT0284	Clutch Cam	TGT0430	Drag Spring Washer (10L)	TGT0466	Ball Bearing
TGT0285	Clutch Lever Screw	TGT0431	Drag Spring Washer (10H)	TGT0467	"BR" Set Plate
TGT0286	Roller Clutch Inner Tube	TGT0433	Bearing Seal	TGT0468	Left Side Plate
TGT0295	Click Pin	TGT0434	Side Plate Screw	TGT0470	"BR" Bushing
TGT0296	Click Spring	TGT0435	Multi-Purpose Screw	TGT0471	"BR" Dial
TGT0303	Anti-Reverse Pawl	TGT0437	Cast Control Cap	TGT0472	Click Button
TGT0305	Multi-Purpose Screw	TGT0438	"O" Ring	TGT0477	Right Side Plate
TGT0319	"BR" Cam Pin	TGT0439	Clutch Lever	TGT0478	One-Piece Frame
TGT0320	"BR" Cam	TGT0440	Line Clip	TGT0479	Spool Assembly
TGT0321	"BR" Friction Washer	TGT0441	Key Washer	TGT0481	Bearing Thrust Washer
TGT0322	"BR" Washer (C)	TGT0442	Drag Washer (D)		
TGT0323	"BR" Washer (A)	TGT0443	Eared Washer (E)		
TGT0324	"BR" Gear (C)	TGT0444	Key Washer (C)	TGT0353	Rod Clamp (accessory)
TGT0325	"BR" Washer (B)	TGT0445	Drag Washer (B)	TGT0473	Rod Clamp Bolt (accessory)
TGT0326	Click Pawl Spring	TGT0446	Drive Gear	TGT0474	Rod Clamp Nut (B) (accessory)
TGT0329	Spacer (B)	TGT0447	Drag Washer (A)	TGT0475	Rod Clamp Nut (A) (accessory)
TGT0330	Click Pawl	TGT0448	Anti-Reverse Ratchet		
TGT0331	Click Pawl Spacer	TGT0449	Drive Shaft		
TGT0332	Click Spring Retainer	TGT0450	Yoke Spring	TGT0476	Wrench (accessory)