




# BAIT CASTING REEL

# CAIMAN

# CA205R



## Key NO.

## Parts No.

## Parts name

1	2F5-097-02	HANDLE NUT CAP
2	2E3-016-01	NUT
3	2YH-079-03	HANDLE ASSEMBLY
4	2E2-030-02	F20M-050 SCREW
5	2E4-018-01	RETAINER
6	2F8-050-01	CLICK LEAF SPRING HOLDER
7	2L3-029-01	STAR DRAG CLICK LEAF SPRING
8	2D4-008-03	STAR DRAG LEVER
9	2Q1-052-01	STAR DRAG SPRING
10	2E3-029-01	STAR DRAG NUT
11	2W1-020-01	081-130 WASHER
12	2L1-004-01	SPRING WASHER
13	2W1-035-05	080-105 WASHER
14	2Z1-024-05	812-2.5 BALL BEARING
15	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
16	2E3-024-01	CAST CONTROL NUT
17	2W5-026-01	SPACER
18	2W5-029-01	CAST CONTROL SPACER
19	2E4-019-01	BEARING RETAINER
20	2Z1-001-05	508-2.5 BALL BEARING
21	2E9-005-01	O RING
22	2E0-011-01	RIGHT SIDE COVER SCREW
23	2W1-132-01	036-060 WASHER
24	2YF-074-03	RIGHT SIDE COVER ASSYMBLY
25	2E5-006-01	E2.5 RETAINER
26	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING
27	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
28	2W2-032-01	KEY WASHER
29	2W1-126-01	082-210 WASHER
30	2W3-017-01	EARED WASHER
31	2W1-111-01	100-230 WASHER
32	2W2-025-01	KEY WASHER
33	2G1-027-01	DRIVE GEAR
34	2YG-023-01	OSCILLATING GEAR ASSYMBLY
35	2A3-027-01	RATCHET
36	2M3-053-01	DRIVE SHAFT
37	2Z1-018-05	510-3 BALL BEARING

## Key NO.

## Parts No.

## Parts name

38	2G2-010-01	PINION GEAR
39	2Q1-031-01	YOKE SPRING
40	2A2-039-01	PINION YOKE
41	2E2-047-01	A20M-065 SCREW
42	2F8-030-01	CLUTCH CAM RETAINER
43	2YA-035-01	CLUTCH CAM ASSEMBLY
44	2Z1-010-05	812-3.5 BALL BEARING
45	2M2-003-01	OSCILLATING SLIDER
46	2Q3-086-01	RETRACTOR SPRING
47	2F8-039-01	GEAR SETTING PLATE
48	2E2-005-03	B26M-080 SCREW
49	2W1-054-01	052-080 WASHER
50	2W1-070-01	052-080 WASHER
51	2E5-013-01	E3.0 RETAINER
52	2YS-083-01	SPOOL ASSEMBLY
53	2C2-057-01	BRAKE COLLAR
54	2Z1-023-05	814-4 BALL BEARING
55	2F3-041-01	CLICK GEAR
56	2YB-098-01	BODY ASSEMBLY
57	2E2-034-01	A20M-090 SCREW
58	2C4-005-01	LEVEL WIND GUARD
59	2E2-003-01	B26M-036 SCREW
60	2C4-013-01	CASTING BAR GUIDE A
61	2C4-014-01	CASTING BAR GUIDE B
62	2YS-085-01	CASTING BAR ASSEMBLY
63	2P2-021-01	CASTING BAR PIN
64	2P4-008-03	CASTING BAR SUPPORT
65	2E4-011-01	BEARING RETAINER
66	2W5-015-01	CAST CONTROL SPACER
67	2F6-032-01	CLICK PLATE
68	2F2-020-01	CLICK SPRING
69	2E2-022-01	B20M-030 SCREW
70	2F4-018-01	CLICK PAWL
71	2F5-108-04	LEFT SIDE COVER
72	2F7-004-01	CLICK SWITCH
73	2X3-004-01	WRENCH
74	2YT-143-01	SPOOL ASSEMBLY