



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-02	DRAG KNOB ASSEMBLY	28	2F5-403-01	ROLLER CLUTCH RETAINER
2	2E4-034-01	DRAG WASHER RETAINER	29	2Q2-021-01	SPRING
3	2W2-071-01	KEY WASHER	30	2YZ-022-01	ONE-WAY CLUTCH BEARING
4	2W1-226-01	080-260 WASHER	31	2A4-072-01	ONE-WAY CLUTCH INNER TUBE
5	2YT-409-02	SPOOL TOTAL ASSEMBLY	32	2Z1-003-07	714-5 BALL BEARING
6	2W2-020-01	KEY WASHER	33	2G2-148-01	PINION GEAR
7	2L3-014-01	CLICK LEAF SPRING	34	2E1-037-01	B30-080 SCREW
8	2M3-133-01	MAIN SHAFT	35	2B1-157-02	BODY
9	2F8-013-01	CLICK LEAF SPRING HOLDER	36	2Z1-009-07	711-3 BALL BEARING
10	2W2-015-01	KEY WASHER	37	2G1-139-01	DRIVE GEAR
11	2E3-007-01	ROTOR NUT	38	2W1-035-00	080-105 WASHER
12	2E1-036-01	B26-040 SCREW	39	2Z1-023-07	814-4 BALL BEARING
13	2R1-134-02	ROTOR	40	2M2-018-01	OSCILLATING CAM
14	2R4-178-02	BAIL TRIP COVER	41	2G3-084-01	OSCILLATING GEAR
15	2E1-020-02	B22-055 SCREW	42	2M1-067-01	OSCILLATING SLIDER
16	2E2-094-01	B30M-090 SCREW	43	2E2-030-02	F20M-050 SCREW
17	2R2-061-02	BAIL ARM	44	2B2-112-02	BODY COVER
18	2E1-025-01	b30-080 SCREW	45	2E1-055-01	A26-100 SCREW
19	2C1-034-01	LINE ROLLER COLLAR	46	2YH-372-01	HANDLE TOTAL ASSEMBLY
20	2Z1-012-07	407-2.5 BALL BEARING	47	2C3-042-01	HANDLE SCREW SLEEVE
21	2R6-020-02	LINE ROLLER	48	2H6-001-12	HANDLE SCREW CAP
22	2C1-120-01	COLLAR	49	2A2-094-02	ANTI-REVERSE CAM
23	2YL-144-02	BAIL ASSMBLY	50	2L5-010-01	ANTI-REVERSE CAM SPRING
24	2Q1-051-02	BAIL SPRING	51	2F5-402-02	REAR COVER
25	2R5-161-01	BAIL TRIP LEVER	52	2E1-020-02	B22-055 SCREW
26	2R4-179-02	BAIL SPRING COVER	LE2500	SPECIAL PARTS	
27	2E1-050-01	A20-060 SCREW	5	2YT-442-02	SPOOL TOTAL ASSEMBLY