



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-04	DRAG KNOB ASSEMBLY	26	2F5-403-01	ROLLER CLUTCH RETAINER
2	2E4-034-01	DRAG WASHER RETAINER	27	2Q2-021-01	SPRING
3	2W2-071-01	KEY WASHER	28	2YZ-022-01	ONE-WAY CLUTCH BEARING
4	2W1-226-01	080-260 WASHER	29	2A4-072-01	ONE-WAY CLUTCH INNER TUBE
5	2YT-409-04	SPOOL TOTAL ASSEMBLY	30	2Z1-003-07	714-5 BALL BEARING
6	2W2-020-01	KEY WASHER	31	2G2-148-01	PINION GEAR
7	2L3-014-01	CLICK LEAF SPRING	32	2E1-037-01	B30-080 SCREW
8	2M3-133-01	MAIN SHAFT	33	2YB-232-01	BODY ASSEMBLY
9	2F8-013-01	CLICK LEAF SPRING HOLDER	34	2G1-139-01	DRIVE GEAR
10	2W2-015-01	KEY WASHER	35	2W1-035-00	080-105 WASHER
11	2E3-007-01	ROTOR NUT	36	2M2-018-01	OSCILLATING CAM
12	2E1-036-01	B26-040 SCREW	37	2G3-084-01	OSCILLATING GEAR
13	2R1-134-04	ROTOR	38	2M1-067-01	OSCILLATING SLIDER
14	2R4-178-01	BAIL TRIP COVER	39	2E2-030-02	F20M-050 SCREW
15	2E1-020-02	B22-055 SCREW	40	2YC-109-02	BODY COVER ASSEMBLY
16	2E2-094-01	B30M-090 SCREW	41	2E1-055-01	A26-100 SCREW
17	2R2-061-04	BAIL ARM	42	2YH-365-02	HANDLE TOTAL ASSEMBLY
18	2E1-025-01	b30-080 SCREW	43	2C3-042-01	HANDLE SCREW SLEEVE
19	2C1-034-01	LINE ROLLER COLLAR	44	2H6-001-13	HANDLE SCREW CAP
20	2C1-120-01	COLLAR	45	2A2-094-04	ANTI-REVERSE CAM
21	2R6-020-02	LINE ROLLER	46	2L5-010-01	ANTI-REVERSE CAM SPRING
22	2YL-144-04	BAIL ASSMBLY	47	2F5-402-01	REAR COVER
23	2Q1-051-02	BAIL SPRING	48	2E1-020-02	B22-055 SCREW
24	2R5-161-01	BAIL TRIP LEVER	EE2500	SPECIAL PARTS	
25	2R4-179-01	BAIL SPRING COVER	5	2YT-442-04	SPOOL TOTAL ASSEMBLY
26	2Q3-113-01	ANTI-REVERSE PAWL SPRING			