




SPINNING REEL

GAINER

GA1000(C-R)



Key NO.

Parts No.

Parts name

1	2YD-074-06	DRAG KNOB ASSEMBLY
2	2E9-019-01	PROOF WATER RING
3	2E4-009-01	DRAG WASHER RETAINER
4	2W2-057-01	KEY WASHER
5	2W1-052-01	050-187 WASHER
6	2YT-439-02	SPOOL TOTAL ASSEMBLY
7	2W2-055-01	KEY WASHER
8	2L3-014-01	CLICK LEAF SPRING
9	2F8-013-03	CLICK LEAF SPRING HOLDER
10	2W2-056-01	KEY WASHER
11	2E3-062-01	ROTOR NUT
12	2M3-150-01	MAIN SHAFT
13	2R1-145-01	ROTOR
14	2Q3-108-01	BAIL SPRING
15	2R5-176-01	BAIL TRIP LEVER
16	2R4-200-02	BAIL TRIP COVER
17	2E1-020-02	B22-055 SCREW
18	2R5-175-01	BAIL PAWL
19	2E2-018-01	B30M-080 SCREW
20	2E1-024-01	b30-060 SCREW
21	2R2-068-01	BAIL ARM
22	2C1-056-01	LINE ROLLER COLLAR
23	2Z1-012-05	407-2.5 BALL BEARING
24	2R6-012-02	LINE ROLLER
25	2C2-032-01	LINE ROLLER BUSH
26	2YL-156-01	BAIL ASSEMBLY
27	2R5-165-01	BAIL TRIP SHAFT
28	2W1-199-01	015-027 WASHER
29	2Q1-117-01	BAIL SPRING
30	2C2-128-01	BAIL SPRING GUIDE
31	2R4-201-02	BAIL SPRING COVER
32	2A4-054-01	ONE-WAY CLUTCH INNER TUBE

Key NO.

Parts No.

Parts name

33	2E2-044-01	A20M-050 SCREW
34	2F5-433-01	ROLLER CLUTCH RETAINER
35	2Q2-016-01	SPRING
36	2YZ-023-01	ONE-WAY CLUTCH BEARING ASSEMBLY
37	2E2-014-01	F26M-060 SCREW
38	2C1-090-01	COLLAR
39	2F5-212-01	BEARING RETAINER
40	2Z1-019-05	612-4 BALL BEARING
41	2G2-161-01	PINION GEAR
42	2A2-105-01	ANTI-REVERSE CAM
43	2Q3-102-01	ANTI-REVERSE SPRING
44	2YB-231-03	BODY ASSEMBLY
45	2B2-124-01	BODY COVER (R)
46	2Z1-009-05	711-3 BALL BEARING
47	2M2-023-01	OSCILLATING CAM
48	2G3-091-01	OSCILLATING GEAR
49	2M1-068-01	OSCILLATING SLIDER
50	2E5-060-01	OSCILLATING SLIDER RETAINER
51	2E2-030-02	F20M-050 SCREW
52	2E1-060-01	A26-060 SCREW
53	2G1-142-01	DRIVE GEAR
54	2W1-019-01	071-103 WASHER
55	2B2-125-01	BODY COVER (L)
56	2E1-055-01	A26-100 SCREW
57	2YH-389-01	HANDLE TOTAL ASSEMBLY
58	2C3-042-01	HANDLE SCREW SLEEVE
59	2H6-001-12	HANDLE SCREW CAP
60	2E2-013-02	B20M-060 SCREW
61	2A1-034-08	ANTI-REVERSE LEVER
62	2F5-432-02	REAR COVER
63	2E2-092-01	B20M-050 SCREW