



| Key NO. | Parts No.  | Parts name               | Key NO. | Parts No.     | Parts name                      |
|---------|------------|--------------------------|---------|---------------|---------------------------------|
| 1       | 2YD-094-02 | DRAG KNOB ASSEMBLY       | 29      | 2F5-436-01    | ROLLER CLUTCH RETAINER          |
| 2       | 2E4-034-01 | DRAG WASHER RETAINER     | 30      | 2Q2-021-01    | SPRING                          |
| 3       | 2W2-071-01 | KEY WASHER               | 31      | 2YZ-027-01    | ONE-WAY CLUTCH BEARING ASSEMBLY |
| 4       | 2W1-226-01 | 080-260 WASHER           | 32      | 2A4-082-01    | ONE-WAY CLUTCH INNER TUBE       |
| 5       | 2W3-035-01 | EARED WASHER             | 33      | 2Z1-005-07    | 816-5 BALL BEARING              |
| 6       | 2YT-443-02 | SPOOL TOTAL ASSEMBLY     | 34      | 2G2-165-01    | PINION GEAR                     |
| 7       | 2W2-020-01 | KEY WASHER               | 35      | 2E1-051-01    | D30-080 SCREW                   |
| 8       | 2L3-015-01 | CLICK LEAF SPRING        | 36      | 2B1-173-02    | BODY                            |
| 9       | 2M3-151-01 | MAIN SHAFT               | 37      | 2Z1-009-07    | 711-3 BALL BEARING              |
| 10      | 2F8-019-02 | CLICK LEAF SPRING HOLDER | 38      | 2G1-150-01    | DRIVE GEAR                      |
| 11      | 2W2-015-01 | KEY WASHER               | 39      | 2W1-019-01    | 071-103 WASHER                  |
| 12      | 2E3-002-01 | ROTOR NUT                | 40      | 2Z1-023-07    | 814-4 BALL BEARING              |
| 13      | 2E1-036-01 | B26-040 SCREW            | 41      | 2M2-016-01    | OSCILLATING CAM                 |
| 14      | 2R1-146-02 | ROTOR                    | 42      | 2G3-081-01    | OSCILLATING GEAR                |
| 15      | 2R4-203-02 | BAIL TRIP COVER          | 43      | 2M1-074-01    | OSCILLATING SLIDER              |
| 16      | 2E1-065-01 | B22-065 SCREW            | 44      | 2E2-009-01    | F23M-060 SCREW                  |
| 17      | 2E2-094-01 | B30M-090 SCREW           | 45      | 2B2-126-02    | BODY COVER                      |
| 18      | 2R2-070-02 | BAIL ARM                 | 46      | 2E1-055-01    | A26-100 SCREW                   |
| 19      | 2E1-010-01 | b30-100 SCREW            | 47      | 2YH-385-01    | HANDLE TOTAL ASSEMBLY           |
| 20      | 2W1-258-01 | 030-060 WASHER           | 48      | 2C3-042-01    | HANDLE SCREW SLEEVE             |
| 21      | 2C1-120-01 | COLLAR                   | 49      | 2H6-001-12    | HANDLE SCREW CAP                |
| 22      | 2R6-020-02 | LINE ROLLER              | 50      | 2A2-106-02    | ANTI-REVERSE CAM                |
| 23      | 2Z1-012-07 | 407-2.5 BALL BEARING     | 51      | 2L5-010-01    | ANTI-REVERSE CAM SPRING         |
| 24      | 2YL-158-02 | BAIL ASSEMBLY            | 52      | 2F5-435-02    | REAR COVER                      |
| 25      | 2Q1-051-02 | BAIL SPRING              | 53      | 2E1-020-02    | B22-055 SCREW                   |
| 26      | 2R5-179-01 | BAIL TRIP LEVER          | LE3500  | SPECIAL PARTS |                                 |
| 27      | 2R4-202-02 | BAIL SPRING COVER        | 6       | 2YT-459-02    | SPOOL TOTAL ASSEMBLY            |
| 28      | 2E1-050-01 | A20-060 SCREW            |         |               |                                 |